

ENGLISH

Pellet-burning boiler ECOMPACT 150-190-250-290

INSTALLATION, USE, MAINTENANCE AND
HELPFUL TIPS



KLOVER[®]
FUOCO E PASSIONE

DICHIARAZIONE DI CONFORMITÀ



DECLARATION OF CONFORMITY

Emesso da - *Issued by* : **KLOVER s.r.l.**
Indirizzo - *Address* : **Via A. Volta, 8**
37047 San Bonifacio (VR)

Tipo di apparecchio - *Type of equipment* : **Heating boiler for solid fuel automatically stoked**

Marchio commerciale - *Trademark* : **KLOVER**

Modello o tipo - *Model or type* : **ECOMPACT 150**

Uso - *Use* : **Central heating in residential buildings**

Costruttore - *Manufacturer* : **KLOVER s.r.l.**

L'oggetto della presente dichiarazione è conforme alle seguenti direttive UE:
The object of this declaration is comply with the following EU directives

2006/42/CE Direttiva macchine.
2006/42/CE Machinery Directive.

2014/35/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla messa a disposizione sul mercato del materiale elettrico destinato ad essere adoperato entro taluni limiti di tensione.

2014/35/UE 26 February 2014 on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.

2014/30/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla compatibilità elettromagnetica.
2014/30/UE 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility.

2011/65/UE del 21 Luglio 2016 relativa l'armonizzazione delle legislazioni degli stati membri relative alla restrizione all'uso di sostanze pericolose nelle apparecchiature elettriche e elettroniche.

2016/65/UE 21 July 2016 on the harmonization of the laws of the Member States relating to the restriction in use of hazardous substances in electrical and electronic equipment.

Riferimenti alle norme armonizzate:
References to the relevant harmonized standards:

EN 303-5
EN 55014-1 EN 55014-2
EN 61000-3-2 EN 61000-3-3
EN 62233
EN 60335-1
EN 60335-2-102
EN 50581

In qualità di costruttore e/o rappresentante autorizzato della società all'interno della CEE, si dichiara sotto la propria responsabilità che gli apparecchi sono conformi alle esigenze essenziali previste dalle Direttive su menzionate.

As the manufacturer's authorised representative within the EEC, we hereby declare under our sole responsibility that the equipment complies with the provisions of the Directives stated above.

San Bonifacio (VR), 22/03/2018

Mario Muraro
Chairman of the Board

DICHIARAZIONE DI CONFORMITÀ



DECLARATION OF CONFORMITY

Emesso da - *Issued by* : **KLOVER s.r.l.**
Indirizzo - *Address* : **Via A. Volta, 8**
37047 San Bonifacio (VR)

Tipo di apparecchio - *Type of equipment* : **Heating boiler for solid fuel automatically stoked**

Marchio commerciale - *Trademark* : **KLOVER**

Modello o tipo - *Model or type* : **ECOMPACT 190**

Uso - *Use* : **Central heating in residential buildings**

Costruttore - *Manufacturer* : **KLOVER s.r.l.**

L'oggetto della presente dichiarazione è conforme alle seguenti direttive UE:
The object of this declaration is comply with the following EU directives

2006/42/CE Direttiva macchine.
2006/42/CE Machinery Directive.

2014/35/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla messa a disposizione sul mercato del materiale elettrico destinato ad essere adoperato entro taluni limiti di tensione.

2014/35/UE 26 February 2014 on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.

2014/30/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla compatibilità elettromagnetica.
2014/30/UE 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility.

2011/65/UE del 21 Luglio 2016 relativa l'armonizzazione delle legislazioni degli stati membri relative alla restrizione all'uso di sostanze pericolose nelle apparecchiature elettriche e elettroniche.

2016/65/UE 21 July 2016 on the harmonization of the laws of the Member States relating to the restriction in use of hazardous substances in electrical and electronic equipment.

Riferimenti alle norme armonizzate:
References to the relevant harmonized standards:

EN 303-5
EN 55014-1 EN 55014-2
EN 61000-3-2 EN 61000-3-3
EN 62233
EN 60335-1
EN 60335-2-102
EN 50581

In qualità di costruttore e/o rappresentante autorizzato della società all'interno della CEE, si dichiara sotto la propria responsabilità che gli apparecchi sono conformi alle esigenze essenziali previste dalle Direttive su menzionate.

As the manufacturer's authorised representative within the EEC, we hereby declare under our sole responsibility that the equipment complies with the provisions of the Directives stated above.

San Bonifacio (VR), 22/03/2018

Mario Muraro
Chairman of the Board

DICHIARAZIONE DI CONFORMITÀ



DECLARATION OF CONFORMITY

Emesso da - *Issued by* : **KLOVER s.r.l.**
Indirizzo - *Address* : **Via A. Volta, 8**
37047 San Bonifacio (VR)

Tipo di apparecchio - *Type of equipment* : **Heating boiler for solid fuel automatically stoked**

Marchio commerciale - *Trademark* : **KLOVER**

Modello o tipo - *Model or type* : **ECOMPACT 250**

Uso - *Use* : **Central heating in residential buildings**

Costruttore - *Manufacturer* : **KLOVER s.r.l.**

L'oggetto della presente dichiarazione è conforme alle seguenti direttive UE:
The object of this declaration is comply with the following EU directives

2006/42/CE Direttiva macchine.
2006/42/CE Machinery Directive.

2014/35/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla messa a disposizione sul mercato del materiale elettrico destinato ad essere adoperato entro taluni limiti di tensione.

2014/35/UE 26 February 2014 on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.

2014/30/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla compatibilità elettromagnetica.
2014/30/UE 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility.

2011/65/UE del 21 Luglio 2016 relativa l'armonizzazione delle legislazioni degli stati membri relative alla restrizione all'uso di sostanze pericolose nelle apparecchiature elettriche e elettroniche.

2016/65/UE 21 July 2016 on the harmonization of the laws of the Member States relating to the restriction in use of hazardous substances in electrical and electronic equipment.

Riferimenti alle norme armonizzate:
References to the relevant harmonized standards:

EN 303-5
EN 55014-1 EN 55014-2
EN 61000-3-2 EN 61000-3-3
EN 62233
EN 60335-1
EN 60335-2-102
EN 50581

In qualità di costruttore e/o rappresentante autorizzato della società all'interno della CEE, si dichiara sotto la propria responsabilità che gli apparecchi sono conformi alle esigenze essenziali previste dalle Direttive su menzionate.

As the manufacturer's authorised representative within the EEC, we hereby declare under our sole responsibility that the equipment complies with the provisions of the Directives stated above.

San Bonifacio (VR), 17/07/2017

Mario Muraro
Chairman of the Board

DICHIARAZIONE DI CONFORMITÀ



DECLARATION OF CONFORMITY

Emesso da - *Issued by* : **KLOVER s.r.l.**
Indirizzo - *Address* : **Via A. Volta, 8**
37047 San Bonifacio (VR)

Tipo di apparecchio - *Type of equipment* : **Heating boiler for solid fuel automatically stoked**

Marchio commerciale - *Trademark* : **KLOVER**

Modello o tipo - *Model or type* : **ECOMPACT 290**

Uso - *Use* : **Central heating in residential buildings**

Costruttore - *Manufacturer* : **KLOVER s.r.l.**

L'oggetto della presente dichiarazione è conforme alle seguenti direttive UE:
The object of this declaration is comply with the following EU directives

2006/42/CE Direttiva macchine.
2006/42/CE Machinery Directive.

2014/35/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla messa a disposizione sul mercato del materiale elettrico destinato ad essere adoperato entro taluni limiti di tensione.

2014/35/UE 26 February 2014 on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.

2014/30/UE del 26 Febbraio 2014 relativa l'armonizzazione delle legislazioni degli stati membri relative alla compatibilità elettromagnetica.
2014/30/UE 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility.

2011/65/UE del 21 Luglio 2016 relativa l'armonizzazione delle legislazioni degli stati membri relative alla restrizione all'uso di sostanze pericolose nelle apparecchiature elettriche e elettroniche.

2016/65/UE 21 July 2016 on the harmonization of the laws of the Member States relating to the restriction in use of hazardous substances in electrical and electronic equipment.

Riferimenti alle norme armonizzate:
References to the relevant harmonized standards:

EN 303-5
EN 55014-1 EN 55014-2
EN 61000-3-2 EN 61000-3-3
EN 62233
EN 60335-1
EN 60335-2-102
EN 50581

In qualità di costruttore e/o rappresentante autorizzato della società all'interno della CEE, si dichiara sotto la propria responsabilità che gli apparecchi sono conformi alle esigenze essenziali previste dalle Direttive su menzionate.

As the manufacturer's authorised representative within the EEC, we hereby declare under our sole responsibility that the equipment complies with the provisions of the Directives stated above.

San Bonifacio (VR), 17/07/2017

Mario Muraro
Chairman of the Board

CONTENTS

CONTENTS	1
INTRODUCTION.....	3
IMPORTANT SAFETY INSTRUCTIONS	3
THE MACHINE AND THE PELLETS	4
COMPONENTS OF THE APPLIANCE	4
OVERALL DIMENSIONS ECOMPACT 150 - 190	6
OVERALL DIMENSIONS ECOMPACT 250 - 290	7
CONNECTIONS DATA SHEET ECOMPACT 150 - 190	8
CONNECTIONS DATA SHEET ECOMPACT 250 - 290	9
TECHNICAL SPECIFICATIONS ECOMPACT 150	10
TECHNICAL SPECIFICATIONS ECOMPACT 190	11
TECHNICAL SPECIFICATIONS ECOMPACT 250	12
TECHNICAL SPECIFICATIONS ECOMPACT 290	13
PELLET PROPERTIES	14
REQUIREMENTS OF THE PLACE OF INSTALLATION.....	14
POSITIONING.....	14
SPACES AROUND AND ABOVE THE APPLIANCE.....	15
EXTERNAL AIR INTAKE	15
THE FLUE AND CONNECTION TO THE SAME.....	16
CHIMNEY	17
ELECTRICAL CONNECTION	18
CONTROL OF ANY COUPLED BOILER	18
CONTROL OF A POSSIBLE THREE-WAY MOTORIZED VALVE FOR DHW SYSTEM MANAGEMENT	18
CONNECTION TO THE ROOM THERMOSTAT	19
HYDRAULIC CONNECTION	19
THE DISPLAY	20
THE MENU	23
INITIAL START-UP	26
SYSTEM CONFIGURATION	26
FILLING THE SYSTEM FOR THE FIRST TIME.....	28
PELLET LOADING AND CONNECTION TO THE MAINS POWER SUPPLY.....	29
IGNITION CYCLE.....	29
SWITCH-OFF CYCLE.....	29
MODIFYING THE WORKING POWER	30
CHANGING THE WATER TEMPERATURE BOILER OR PUFFER.....	30
PROBLEMS, ALARMS, USEFUL ADVICES	31
USEFUL INFO... ..	31
WHAT HAPPENS IF... ..	31
ALARM SIGNALS	32
CLEANING AND MAINTENANCE	33
PRECAUTIONS BEFORE CLEANING	33
ROUTINE CLEANING	33
NON-ROUTINE CLEANING	35
CLEANING THE CERAMIC GLASS	36
CLEANING THE FLUE	37
MAINTENANCE	37

PCB PARAMETERS	38
PARAMETER TABLES ECOMPACT 150.....	38
PARAMETER TABLES ECOMPACT 190.....	40
PARAMETER TABLES ECOMPACT 250.....	42
PARAMETER TABLES ECOMPACT 290.....	44
WIRING DIAGRAM.....	46
STANDARD WARRANTY CONDITIONS.....	47

Dear client,

First of all we would like to thank you for choosing a “KLOVER” product and we hope you will be satisfied with this product.

Read carefully the warranty certificate on the last page of this *User guide*.

We would like to thank you again for trusting KLOVER products, and we would also like inform you that these models are the result of forty years of experience in the manufacture of solid fuel products using water as heat transfer fluid. Every single detail of the product is manufactured by qualified staff, using the most advanced equipment.

The manual contains a detailed description of the appliance and its operation, instructions for proper installation, basic maintenance and control points, which must be periodically performed; furthermore it contains practical advice which helps to obtain maximum performance from the appliance with minimum fuel consumption.

Stay warm with KLOVER!

Copyright

All rights reserved. The reproduction of any part of this manual, in any form, without the explicit written permission of KLOVER Srl. is forbidden. The content of this manual may be modified without notice. Although the documentation contained in this manual has been carefully compiled and checked, KLOVER srl cannot be held liable for any damages arising from the use of the same.

Copyright © 2018 KLOVER srl

INTRODUCTION

Important safety instructions

Please read these instructions before installing and using the product.

- The installation and initial start-up of the appliance must be performed by skilled personnel trained in the relevant safety standards. They will be responsible for the definitive installation of the appliance and its proper operation. KLOVER srl shall not be held liable if these precautions are not observed.
- During the installation and use of the appliance, all local regulations - including those referring to national and European Standards - must be observed.
- Connect the flue gas outlet to a flue with the specifications described in the “Flue and its connection” section of this User guide.
- The appliance is not suitable for installation on a shared flue system.
- If the flue should catch fire, use appropriate fire extinguishing equipment or call the fire brigade.
- Connect the product to an earthed power socket. Avoid using sockets controlled by switches or automatic timers.
- Do not use the power supply cable if damaged or worn.
- If a multiple socket is used, make sure that the total voltage of the connected devices does not exceed the rated voltage for the socket. Also make sure that the total voltage of all the devices connected to the socket does not exceed the maximum permitted level.
- The plug on the appliance’s power cable should be connected only once the assembly and installation of the appliance is complete. It should remain accessible after installation if the appliance is not fitted with a suitable and accessible two-pole switch.
- Do not use flammable substances to clean the appliance or its parts.
- Do not leave flammable containers and substances in the place where the appliance is installed.
- The appliance works exclusively with wood pellets and only with the hearth door shut.
- NEVER open the door of the appliance during normal operation.
- The use of poor quality pellets or any other material can damage the appliance operation, voiding the warranty and exempting the manufacturer from all liability.
- Do not use the appliance as an incinerator or for any use other than that for which it was designed.
- Do not use fuels other than those recommended.
- Do not use liquid fuels.
- The appliance, and its outer surfaces in particular, become very hot to the touch during operation; handle with caution in order to avoid burns.
- Keep fuel and flammable materials at a safe distance.
- Only use original spare parts recommended by the manufacturer.
- Do not make any unauthorised modifications to the appliance.
- Do not touch the hot components of the product (ceramic glass, flue pipe) during normal operation.
- Never touch the appliance if you are barefoot and/or if you have wet or damp parts of the body.
- Use the appropriate button to switch off the electrical panel. Do not disconnect the power supply cable while the appliance is operating.
- During the ignition phase and normal operation of the appliance, maintain the necessary safety distance and do not remain standing in front of it.
- Keep children away from the appliance when it is running since they could get burned by touching its hot components.
- Do not leave the packaging elements within reach of children or unassisted disabled persons.
- Children and inexperienced people must not be allowed to use the appliance.
- The appliance may be used by children no younger than 8 years of age and people with reduced physical, sensory or mental capabilities, or those without experience of the appliance, as long as they are supervised or have received instructions on how to use the appliance safely and understand the hazards inherent to the appliance.
- Children should not play with the appliance.
- User maintenance and cleaning operations should not be carried out by unsupervised children.
- Do not use the appliance in ways other than those indicated in this user guide.
- The appliance is designed for indoor use only.
- The appliance is designed for heating water and should therefore be connected to a plumbing system (radiators, under-floor heaters, etc.). This system should be suitably designed and sized to distribute the power generated by the appliance.

- This user guide constitutes an integral part of the appliance. If the product is sold to another user, this manual must be passed on to the new owner.

KLOVER S.R.L. DECLINES ALL LIABILITY IN CASE OF ACCIDENTS DUE TO FAILURE TO COMPLY WITH THE SPECIFICATIONS OF THIS MANUAL.

KLOVER S.R.L. DECLINES ALL LIABILITY DUE TO INCORRECT USE OF THE PRODUCT BY THE USER, UNAUTHORISED MODIFICATION AND/OR REPAIRS, AND USE OF NON-ORIGINAL SPARE PARTS OR SPARE PARTS NOT SPECIFICALLY DESIGNED FOR USE ON THIS PRODUCT MODEL.

KLOVER S.R.L. SHALL NOT BE HELD LIABLE FOR THE STOVE'S INSTALLATION. THE INSTALLER IS THE SOLE PARTY RESPONSIBLE FOR THIS OPERATION AND IS ALSO ENTRUSTED WITH CHECKING THE FLUE, EXTERNAL AIR VENT AND THE CORRECTNESS OF THE PROPOSED INSTALLATION SOLUTIONS. ALL THE SAFETY REGULATIONS SET OUT IN THE SPECIFIC LAWS IN FORCE IN THE COUNTRY WHERE THE MACHINE IS INSTALLED MUST BE OBSERVED.

NON-ROUTINE MAINTENANCE MUST ONLY BE PERFORMED BY AUTHORISED AND QUALIFIED STAFF.

To ensure the validity of the warranty, the user must comply with the instructions contained in this guide and, in particular, must:

- Use the appliance within its operating limits;
- Regularly perform all maintenance activities;
- Authorise expert and competent people to use the appliance.

Failure to comply with the instructions contained in this guide shall automatically void the warranty.

THE MACHINE AND THE PELLETS


Components of the appliance


The table below shows the standard features of the appliance:


Expansion tank	10 l
Safety valve	2.5 bar
Pressure gauge	0 – 4 bar
Automatic air vent valve	Yes
Heating system pump	Yes. Mod.25/70
Electrical setting for the connection of the domestic water flow switch	Yes
Electrical setting for boiler / puffer sensor	Yes
Electrical setting for the control of the optional automatic pellet loader	Yes
Remote control	Optional

The appliance is delivered with the following equipment:


- No. 1 - user, installation and maintenance guide;
- No. 1 - power supply cable;



Overall dimensions ECOMPACT 150 - 190

Overall dimensions ECOMPACT 250 - 290

Connections data sheet ECOMPACT 150 - 190



Description of connections

M = System Delivery	3/4" M
R = System Return	3/4" M
F = Domestic cold water inlet (on prepared models only)	1/2" M
C = Domestic hot water outlet (on prepared models only)	1/2" M
S = Upper or rear flue gas outlet	100 mm M
A = Rear or side fitting for connection of optional extraction pipe	40 mm
E = Electrical cable outlet	

Connections data sheet ECOMPACT 250 - 290



Description of connections

M = System Delivery	3/4" M
R = System Return	3/4" M
F = Domestic cold water inlet (on prepared models only)	1/2" M
C = Domestic hot water outlet (on prepared models only)	1/2" M
S = Upper or rear flue gas outlet	100 mm M
A = Rear or side fitting for connection of optional extraction pipe	50 mm
E = Electrical cable outlet	

Technical specifications ECOMPACT 150

Heat input (nominal setting)	kW (Kcal/h)	15.7 (13,500)
Heat input (reduced setting)	kW (Kcal/h)	4.5 (3,850)
Nominal thermal output	kW (Kcal/h)	14.6 (12,550)
Reduced thermal power	kW (Kcal/h)	4.2 (3,600)
Efficiency delivered to water at nominal thermal power	%	92.6
Efficiency delivered to water at reduced thermal power	%	93.3
CO at 10% oxygen at nominal thermal power	%	0.010
CO at 10% oxygen at reduced thermal power	%	0.033
Maximum power uptake	Watt	430*
Power uptake during operation at nominal thermal power	Watt	63
Power uptake during operation at reduced thermal power	Watt	35
Power uptake in stand-by	Watt	2
Nominal voltage	V	230
Nominal frequency	Hz	50
Expansion vessel litres/preloading bar		10 / 1
Maximum operating/recommended pressure	bar	2.5 / 1.5
Flue outlet diameter	mm	100
Air intake pipe diameter	mm	40
Minimum chimney draught at nominal thermal power	Pa	10.5
Minimum chimney draught at reduced power	Pa	6.7
Combustion gas mass at nominal thermal power	g/s	10.3
Combustion gas mass at reduced power	g/s	4.5
Pellet tank capacity	Kg	55
Average exhaust flue gas temperature at nominal thermal power	°C	107.3
Average exhaust flue gas temperature at reduced power	°C	85.2
Boiler unit capacity	litres	42
Width	mm	1120
Height	mm	1150
Depth	mm	500
Minimum safety distance from flammable materials (side/rear)	mm	200 / 200
Weight	Kg	300

* Power consumption only during the ignition cycle.

The appliance's heat output may vary depending on the type of pellets used.

Technical specifications ECOMPACT 190

Heat input (nominal setting)	kW (Kcal/h)	19.7 (16,950)
Heat input (reduced setting)	kW (Kcal/h)	4.5 (3,850)
Nominal thermal output	kW (Kcal/h)	18.2 (15,650)
Reduced thermal power	kW (Kcal/h)	4.2 (3,600)
Efficiency delivered to water at nominal thermal power	%	92.3
Efficiency delivered to water at reduced thermal power	%	93.3
CO at 10% oxygen at nominal thermal power	%	0.010
CO at 10% oxygen at reduced thermal power	%	0.033
Maximum power uptake	Watt	430*
Power uptake during operation at nominal thermal power	Watt	63
Power uptake during operation at reduced thermal power	Watt	35
Power uptake in stand-by	Watt	2
Nominal voltage	V	230
Nominal frequency	Hz	50
Expansion vessel litres/preloading bar		10 / 1
Maximum operating/recommended pressure	bar	2.5 / 1.5
Flue outlet diameter	mm	100
Air intake pipe diameter	mm	40
Minimum chimney draught at nominal thermal power	Pa	10.0
Minimum chimney draught at reduced power	Pa	6.7
Combustion gas mass at nominal thermal power	g/s	12.3
Combustion gas mass at reduced power	g/s	4.5
Pellet tank capacity	Kg	55
Average exhaust flue gas temperature at nominal thermal power	°C	114.0
Average exhaust flue gas temperature at reduced power	°C	85.2
Boiler unit capacity	litres	42
Width	mm	1120
Height	mm	1150
Depth	mm	500
Minimum safety distance from flammable materials (side/rear)	mm	200 / 200
Weight	Kg	300

* Power consumption only during the ignition cycle.

The appliance's heat output may vary depending on the type of pellets used.

Technical specifications ECOMPACT 250

Heat input (nominal setting)	kW (Kcal/h)	25.8 (22,100)
Heat input (reduced setting)	kW (Kcal/h)	7.5 (6,450)
Nominal thermal output	kW (Kcal/h)	23.3 (20,050)
Reduced thermal power	kW (Kcal/h)	6.5 (5,600)
Combustion efficiency at nominal thermal power	%	95.3
Efficiency delivered to water at nominal thermal power	%	90.3
Combustion efficiency at reduced thermal power	%	93.3
Efficiency delivered to water at reduced thermal power	%	87.9
CO at 10% oxygen at nominal thermal power	%	0.004
CO at 10% oxygen at reduced thermal power	%	0.022
Maximum power uptake	Watt	430*
Power uptake during operation at nominal thermal power	Watt	87
Power uptake during operation at reduced thermal power	Watt	54
Power uptake in stand-by	Watt	3.2
Nominal voltage	V	230
Nominal frequency	Hz	50
Expansion vessel litres/preloading bar		10 / 1
Maximum operating/recommended pressure	bar	2.5 / 1.5
Flue outlet diameter	mm	100
Air intake pipe diameter	mm	60
Minimum chimney draught at nominal thermal power	Pa	12.6
Minimum chimney draught at reduced power	Pa	10.6
Combustion gas mass at nominal thermal power	g/s	12.7
Combustion gas mass at reduced power	g/s	6.0
Pellet tank capacity	Kg	75
Average exhaust flue gas temperature at nominal thermal power	°C	95.7
Average exhaust flue gas temperature at reduced power	°C	65.4
Boiler unit capacity	litres	52
Width	mm	1180
Height	mm	1220
Depth	mm	570
Minimum safety distance from flammable materials (side/rear)	mm	200 / 200
Weight	Kg	380

* Power consumption only during the ignition cycle.

The appliance's heat output may vary depending on the type of pellets used.

Technical specifications ECOMPACT 290

Heat input (nominal setting)	kW (Kcal/h)	29.7 (25,550)
Heat input (reduced setting)	kW (Kcal/h)	7.3 (6,300)
Nominal thermal output	kW (Kcal/h)	26.8 (23,050)
Reduced thermal power	kW (Kcal/h)	6.6 (5,700)
Combustion efficiency at nominal thermal power	%	95.1
Efficiency delivered to water at nominal thermal power	%	90.1
Combustion efficiency at reduced thermal power	%	94.3
Efficiency delivered to water at reduced thermal power	%	89.7
CO at 10% oxygen at nominal thermal power	%	0.002
CO at 10% oxygen at reduced thermal power	%	0.028
Maximum power uptake	Watt	430*
Power uptake during operation at nominal thermal power	Watt	87
Power uptake during operation at reduced thermal power	Watt	54
Power uptake in stand-by	Watt	3.2
Nominal voltage	V	230
Nominal frequency	Hz	50
Expansion vessel litres/preloading bar		10 / 1
Maximum operating/recommended pressure	bar	2.5 / 1.5
Flue outlet diameter	mm	100
Air intake pipe diameter	mm	60
Minimum chimney draught at nominal thermal power	Pa	11.7
Minimum chimney draught at reduced power	Pa	9.8
Combustion gas mass at nominal thermal power	g/s	15.8
Combustion gas mass at reduced power	g/s	5.5
Pellet tank capacity	Kg	75
Average exhaust flue gas temperature at nominal thermal power	°C	112.3
Average exhaust flue gas temperature at reduced power	°C	65.3
Boiler unit capacity	litres	52
Width	mm	1180
Height	mm	1220
Depth	mm	570
Minimum safety distance from flammable materials (side/rear)	mm	200 / 200
Weight	Kg	380

* Power consumption only during the ignition cycle.

The appliance's heat output may vary depending on the type of pellets used.

Pellet properties

The appliance has been tested with all types of pellets available on the market. The pellets must have the following properties:

- Diameter 6 mm.
- Maximum length 35 mm.
- Maximum humidity content 8 – 9 %.
- 100% wood. Totally additive-free.
- Maximum ash residue 1.1 %.

To obtain good performance from the appliance, we recommend using good quality pellets. **Pellets should be poured into the tank using a shovel, and not directly from the bag.**

Good quality pellets should have the following properties:

- Constant diameter cylinders with a smooth, shiny surface;
- There should not be a lot of sawdust inside the packaging;
- After grabbing a bunch of pellets and placing them into a container filled with water, good-quality pellets will sink and poor-quality ones will tend to float;
- The quality certification data, in particular conformity to international standards such as EN14961-2, DIN 51731 and O-NORM M7135, should be indicated on the packaging;
- The packages should be intact since pellets tend to absorb humidity. Humidity not only reduces the calorific value and increases the amount of flue gases expelled, but also causes swelling of the product which may create problems with the appliance.

The production of pellets must be compliant with some international standards (such as EN14961-2, DIN 51731 and O-NORM M7135) which establish minimum values for quality checks on pellets. To facilitate the right choice of the combustible material you can find below one of the most common certification marks identifying the quality of the pellets:

Indication of the standard,
base reference for the quality
classes EN*plus*

**Indication of the quality
class of the certified pellet**
(preferably A1)



IT xxx

Code of the certified company
consisting of two elements:

- Symbol of the country of production (example "IT")
- Progressive number assigned at the acquisition of the certification (example "xxx")

The use of poor quality pellets or any other material can damage the appliance operation, voiding the warranty and exempting the manufacturer from all liability.

In order to guarantee trouble-free combustion, the pellets must be stored in a dry place.

REQUIREMENTS OF THE PLACE OF INSTALLATION

Positioning

The initial phase for best installation of the appliance is to determine its optimum location; the following elements need to be considered:

- The possibility of creating an external air vent;
- The possibility of creating a straight flue, preferably coaxial to the outlet of the appliance;
- Proximity to the main water drain and/or the boiler (if one already exists);
- Proximity or ease of connection to the water system;
- Ease of access for cleaning the appliance, the flue gas exhaust pipes and the flue.

The unit must be installed on a floor with a suitable load capacity. If the existing building does not fulfil this requirement appropriate measures (e.g. load distribution plate) must be taken.

The minimum safety distance from flammable materials must be at least 200 mm from the sides and 100 mm from the back of the appliance.


The installation must guarantee easy access for cleaning the appliance, the flue gas exhaust pipes and the flue, and any subsequent maintenance operation by the Authorised technical assistance centre.

Once you have found the best location for the appliance, position it following the instructions given below.

The appliance must not be installed in small rooms, bedrooms, bathrooms or in areas with an explosive atmosphere.

Spaces around and above the appliance

The figure below shows the minimum distances from walls or other not-easily-removable furniture, that need to be taken into consideration when positioning the appliance.



Any shelves or false ceilings mounted above the appliance must be at least 50 cm away from the top part of it.

Furniture and movable objects made from flammable materials must be positioned at least 20 cm from the side surfaces of the appliance; these objects must be moved when performing maintenance on the appliance.

Protect all structures that can catch fire against the radiated heat of the fire.

Any extra intervention by the Authorised technical assistance centre, which requires the appliance to be disconnected from the system, will not be covered under warranty as described in the chapter “Standard Warranty Conditions”.

External air intake

During operation, the appliance takes in air from the environment in which it is installed; It is therefore essential that this air is replaced through an external air vent. The absence of the air vent may affect the flue draught and therefore the combustion and the safety of the appliance.

Therefore **it is mandatory** to install an external air vent with a minimum completely free passage of **at least 80 cm²** (round hole with minimum diameter of 15 cm protected with a special fixed large mesh grille).

If it not possible to put the external air vent in the same room as where the appliance is installed, this hole can be made in an adjoining room as long as this room communicates permanently, by means of a transit hole (15 cm minimum diameter).

The hole must be protected externally with a fixed grille. The protective grille must be checked periodically to ensure that it is not obstructed, thereby impeding the passage of air. **Therefore keep the air vents clear of obstructions.**

The UNI 10683 Standard FORBIDS the drawing of combustion air from garages, warehouses storing combustible materials, or from business premises with a fire hazard.

If there are other heating or extraction devices inside the room, the air vents must guarantee a sufficient amount of air for properly operating all the devices.

Only sealed appliances (e.g. C type gas appliances, according to the UNI 7129 Standard) or appliances that do not cause a lower pressure compared with the external environment can pre-exist or be installed in the place where the appliance is installed.

Extractor fans can cause malfunctions to the appliance if used in the same room.


The flue and connection to the same

The flue is an essential element for the efficient operation of the appliance. The flue must have a minimum cross-sectional area as that indicated in the technical specifications of the appliance (120 mm). Each product must be equipped with its own flue, without other adjoining elements (boilers, chimneys, stoves, etc.). The flue dimensions are closely related to its height, which must be measured from the appliance flue gas outlet to the base of the stack. In order to guarantee adequate draught, the surface of the chimney flue outlet must be double the flue cross-section. The discharge pipe for combustion products generated by the forced draught device, must comply with the following requirements:

- It must seal off the combustion gases, as well as being waterproof and suitably isolated and insulated in relation to the conditions of use (refer to UNI 9615);
- It must be made of suitable materials capable of withstanding normal mechanical stress, heat, and the effects of combustion gases and condensate, if any;
- It must go upwards after the vertical section, for the entire remaining part, with a minimum gradient of 5%. The sub-horizontal section must not have a length greater than $\frac{1}{4}$ of the effective height H of the flue or chimney, and **must not be longer than 2,000 mm**;
- It must preferably have a round internal cross-section: square or rectangular cross-sections must have rounded corners with radius not inferior to 20 mm;
- It must have a constant, free and independent internal cross section;
- Rectangular cross-sections must have a maximum ratio of 1.5 between the sides;
- **It must be insulated** to prevent the fumes from cooling and forming condensation;
- Parts made from non-combustible materials (**it is absolutely prohibited the use of aluminium flue**) - capable of withstanding combustion gases and potential condensation - must be used for mounting the flue gas pipes (for the section from the appliance to the flue inlet);
- It is forbidden to use fibre cement pipes to connect the appliance to the flue;
- Flue gas conduits must not pass through rooms in which the installation of combustion devices is prohibited;
- The flue gas conduits must be assembled in such a way as to guarantee adequate sealing of flue gases during low pressure operation of the appliance;
- **The installation of horizontal sections is prohibited;**
- **It is prohibited to use counter sloping elements;**
- The flue gas pipe must allow for the recovery of soot or be cleanable, and must have a constant cross-section;
- It is forbidden to allow other air intake conduits and system pipes to transit inside the flue gas pipes, even if they are over-sized.

FURTHER SPECIFICATIONS TO BE CONSIDERED

- The appliance works with the combustion chamber in depression and the flue pipe in pressure; **it is essential that the flue gas outlet is hermetically sealed.**
- The flue pipes inside the installation room must be made of a suitable material ([see current regulations](#)) and equipped with seal gaskets with a minimum diameter of 120 mm.
- **The pipes must have a double wall (thermally insulated) or be suitably insulated with rock wool. The maximum temperature of the flue pipe inside the room must not exceed 70°C.**
- **IT IS MANDATORY TO HAVE AN INITIAL VERTICAL SECTION OF AT LEAST 0.5 MT IN ORDER TO GUARANTEE CORRECT FLUE GAS DISCHARGE.**
- Every direction change must be carried out with a T-shaped fitting and inspection cap. The tubes must be air tight through special seals which resist up to 250° C. Attach the pipes to the wall with special collars to avoid any vibration.
- **IT IS STRICTLY FORBIDDEN TO INSTALL DRAUGHT REGULATION VALVES (BUTTERFLY VALVES).**



If the flue should be old or too big (internal diameter greater than 15 cm), duct the flue using a stainless steel pipe, properly insulated with rock wool or vermiculite, and sized according to the route. The connection to the flue must be appropriately sealed.

When assembling the flue, there must be no more than 4 direction changes.

Chimney


The **chimney** is a device crowning the flue, used to ease dispersion of combustion products.

It must satisfy the following requirements:

- It must have a usable outlet cross-section no less than double that of the flue onto which it is inserted;
- It must be shaped in such a way as to prevent rainwater or snow from entering the flue;
- It must be built in such a way as to ensure the discharge of combustion by-products even in the event of winds from every direction and inclination.

The outlet height (where height refers to the top of the flue, regardless of any chimney stacks) must be outside of the so-called reflux zone, in order to prevent the formation of counter-pressures preventing the free discharge of combustion by-products into the atmosphere.

It is therefore necessary that the minimum heights - indicated in the following diagrams - are observed:



ELECTRICAL CONNECTION

The electric connection must only be performed by **qualified staff**, in compliance with all general and local safety standards.

Check that the power supply voltage and frequency correspond to 230V – 50 Hz.

The appliance's safety is ensured when it is properly connected to an efficient earthing system.

In the electric connection to the mains power supply, include a 6 A – Id 30 mA differential trip-switch with suitable breaking load. The electric connections, including the earth connection, must be made after shutting off the electrical system.


When completing the system, bear in mind that the cables must be laid in an unmovable manner and far from parts subject to high temperatures. During the final wiring of the circuit, only use components with a suitable electrical protection rating. Do not pass electric cables in the immediate vicinity of the flue gas pipe, unless they are insulated with suitable materials.

KLOVER srl declines all responsibility for injury to persons and animals or damage to objects due to failure to connect the appliance to earth or to comply with IEC specifications.

Control of any coupled boiler

If the pellet appliance is to be coupled with a previously installed boiler in the system (e.g. wall-hung gas boiler), you must ensure that the standard boiler stops when the pellet appliance takes over the heating of the system. The electrical setting, which is accessible from the *left-hand technical compartment*, intervenes on the standard boiler when the heating circulating pump of the pellet appliance starts up so as to avoid having two boilers operating simultaneously on the same system. The coupled boiler is however always available for the production of domestic hot water.

The two wires fitted on the left-hand technical compartment of the appliance (blue and brown wires) will have an output voltage of 230 V when the pellet appliance pump is working, and no voltage when the pump stops. It is therefore necessary to connect the 2 wires to a relay that will control the Room Thermostat (R.T.) input of the coupled boiler (see the following example).



Control of a possible three-way motorized valve for DHW system management


The pellet appliance is equipped as standard with a control for a possible 3-way motorised valve to be installed on the domestic water circuit based on the selected system type (see “*System configuration*”). In the left-hand technical compartment of the appliance there are four wires with fastons protected by a red seal, which can be used for controlling the valve (see also “*wiring diagram*”). The four wires have different colours, and precisely:

- Blue wire = 3-WAY VALVE COMMON (Neutral 230 V)
- Black wire = SANITARY SIDE (Phase 230 V with DHW demand)
- Black wire = HEATING SIDE (Phase 230 V with no DHW demand)
- Yellow/green wire = GND

Connection to the room thermostat

On the left-hand technical compartment of the appliance there is a bridged terminal which is used to connect the room thermostat that will command the operation. The operation of the room thermostat is enabled with system types 1, 2 and 3 (see “System configuration”).

OPERATING PRINCIPLE



Open contact:

- The appliance switches directly to economy mode operation “T-AMB ECONOMY” thus minimising its operating power.
- The heating circulating pump of the appliance switches off.
- The temperature in the boiler increases due to thermal inertia until it reaches the temperature set with “SET H2O” and displays “T-H2O ECONOMY” on its monitor.
- The appliance now switches itself off automatically if at least one of the following conditions occurs:
 - If it remains in Economy mode Operation “T-H2O ECONOMY” for a time set on Pr44 (20 minutes as default setting).
 - If it exceeds the temperature differential set on Pr43 (set as default at 5°C), in other words if Temperature H2O > (“SET H2O” + Pr43).
- The appliance will switch on again automatically if both of the following conditions occur:
 - The contact of the room thermostat closes.
 - If it goes below the temperature differential of the “SET H2O”.

If the above condition occurs during the switch-off cycle, please wait until the cycle is complete.

N.B.: If the water temperature exceeds the set threshold of 80°C (safety temperature), the circulating pump of the system is forcedly switched-on to ensure the disposal of excessive heat, thus avoiding high water temperatures in the boiler. For this reason it is recommended that the heating system is not entirely closed.

In the configuration “System type 3”, the appliance switches to economy mode and then switches off only if the “SET BOILER” temperature setting has been reached.

ATTENTION: In the event that the room sensor in the “Remote control” for the appliance is enabled, the appliance switches to economy mode if the “SET ROOM” temperature setting has also been reached.

HYDRAULIC CONNECTION

The plumbing connections must be made in a rational way using the connections on the template of the appliance. To facilitate connection of the pipes, all plumbing attachments have been fitted to the upper part of the appliance. The appliance can be coupled with any other boiler already installed on the system. In this case it is essential to fit all the necessary safety devices and shut-off valves based on the system and intended use. It is also necessary to consider all laws and national, regional, provincial and municipal regulations of the country where the appliance is installed.

The appliance can be installed with the expansion vessel closed because it is equipped with a device for stopping fuel loading, a safety manual reset thermostat and an audible alarm, which are activated if the temperature becomes too high.

You can install the appliance in the same room as another boiler only if this has a sealed chamber; installation must be performed in compliance with the current regulations.

When installing the appliance, it is advisable to fit an anti-condensation mixer valve between the delivery and return pipes on the appliance’s heating system. The anti-condensation valve should be calibrated to 55°C with a Kv value equal to or greater than 8 m³/h.

When connecting the appliance to the system, you should provide a zone that is always open (such as bathroom area) to enable the excess heat dissipation of the water in the body of the boiler.

The maximum mains water pressure should never exceed 2.5 bar; recommended operating pressure is 1.5 bar (with the appliance in operation).

In the event of water with hardness exceeding 28 °f, an anti-limescale device must be installed. This must be selected on the basis of the specific properties of the water.

TO AVOID COMPROMISING THE OPERATION AND LIFE OF THE HEAT PUMP, INSTALLATION OF A FILTER AND A MAGNETIC DIRT SEPARATOR IS RECOMMENDED DOWNSTREAM OF THE RETURN PIPE ON THE APPLIANCE.


The appliance must be mounted exclusively by qualified personnel. Scrupulously comply with the instructions given in this guide.


The manufacturer declines any liability for damages caused due to incorrect assembly.

THE DISPLAY

The appliance's operating mode is displayed on the console. After turning on the menu, it is possible to choose from many types of display and available settings according to the selected menu.

The figures below show the display when the appliance is in ON mode.





The following figure describes the meanings of the status signals appearing on the left side of the display (*1st LED SERIES*).



ROOM THERMOSTAT: the LED is on when the thermostat contact is open.

PROGRAMMABLE THERMOSTAT: the LED lights up when at least one start-up and switch-off program is active.

IGNITION PLUG: the LED is on when the ignition plug is active.

SCREW FEED: the LED lights up when the pellet loading gear motor is started.


FLUE GAS EXTRACTOR: the LED lights up when the flue gas extractor is active.

DHW DEMAND: the LED lights up when the DHW flow switch contact is closed (which means there is demand for hot water) or the DHW storage boiler or puffer (where fitted) is in demand.

PUMP: the LED lights up when the system circulation pump is active.


ALARM: the LED lights up when the boiler is in a state of alarm.

The meanings of the status signals appearing on the top right side of the display are described below (*2nd LED SERIES*).



- LED 1: the LED lights up when the daily programme of the on off settings is active.
- LED 2: the LED lights up when the weekly programme of the on off settings is active.
- LED 3: the LED lights up when the weekend programme of the on off settings is active.
- LED 4: the LED lights up (flashing) when the operation parameters are being edited.
- LED 5: the LED lights up when the summer function is active.
- LED 6: the LED lights up when the winter function is active.
- LED 7: the LED is not currently used.

The following diagram shows the display when setting or programming operating parameters.



The INPUT area shows the entered programming values.
 The MENU LEVEL area shows the current parameter/menu level.
 The DIALOGUE area displays the meaning of the current parameter/menu.

The table explains how the buttons on the display work.

KEY	DESCRIPTION	MODE	ACTION
1	Increase temperature (1)	Programming mode..	Changes/increases the value of the selected menu item.
		Working/off..	It increases the temperature of the room/water thermostat.
2	Decrease temperature (2)	Programming mode..	Changes/decreases the value of the selected menu item.
		Working/off..	It decreases the temperature of the room/water thermostat.
3	Set	-	Enters the menu in question.
		Menu mode..	Accesses the next level of sub-menus.
4	ON/OFF Outlet	Working..	Switches the appliance on and/or off when pressed for 2 seconds.
		In alarm block..	Releases the alarm.
		Menu/programming mode..	Moves you to the previous menu level, saving the changes made.
5	Decrease power (3)	Working/off..	Decreases the working/fan power of the appliance.
		Menu mode..	Moves you to the next menu item.
		Programming mode..	Moves you to the next submenu item, storing the changes made.
6	Increase power (3)	Working/off..	Increases the working/fan power of the appliance.
		Menu mode..	Moves you to the previous menu item.
		Programming mode..	Moves you to the previous submenu item, storing the changes made.

(1) The first press selects "Set temperature for boiler water - SET H2O" or "Set DHW boiler temperature - SET BOILER" or "Set centralised puffer temperature - SET PUFFER" based on the system configuration type.

(2) It selects "Set temperature for boiler water - SET H2O" when first pressed.

(3) It selects the operating power "SET POWER" when first pressed.

THE MENU

Access the Menu by pressing key 3 (Set).

The menu is divided into different items and levels, providing access to the programming and settings options of the appliance.

Buttons 5 and 6 allow you to select the menus to be modified.

Buttons 1 and 2 allow you to change the set value in the selected menu.

Listed below are the menus present on the PCB, with the relevant explanations.

Menu 01 – Choose season

Allows you to set the season for appliance use (SUMMER / WINTER). Can only be used with plumbing system 3 (see “System configuration”).

Menu 02 – Set clock

Allows for setting the current date and time.

Menu 03 – Set timer

Sub-menu 03 – 01 – enable timer

Allows you to globally enable and disable all programmable thermostat functions. For the correct operation it is recommended to enable it (“ON”) when at least one on/off programme (daily, weekly or weekend programme) is activated.

MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 01 – 01	ACTIVATE TIMER	Enable/disable set programs	ON – OFF

Submenu 03 – 02 – daily program

Allows you to enable, disable and set the programmable thermostat daily programme functions.

Two operating time slots can be set according to the following table, where OFF signals the clock to ignore the command:

MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 02 – 01	DAILY TIMER	Enable/disable the daily programme	ON – OFF
03 – 02 – 02	START 1st DAY	Turn-on time of the first programme	Time – OFF
03 – 02 – 03	STOP 1st DAY	Turn-off time of the first programme	Time – OFF
03 – 02 – 04	START 2nd DAY	Turn-on time of the second programme	Time – OFF
03 – 02 – 05	STOP 2nd DAY	Turn-off time of the second programme	Time – OFF

Sub-menu 03 – 03 – weekly program

Allows you to enable, disable and set the programmable thermostat weekly program functions.

MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 03 – 01	WEEK TIMER	Enable/disable the weekly programme	ON – OFF

The weekly programmer has 4 independent on/off programmes; it is not essential to use all four simultaneously. By setting OFF in the time field, the clock ignores the corresponding command.

PROGRAMME 1			
MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 03 – 02	START PROG 1	Turn-on time of the first programme	Time – OFF
03 – 03 – 03	STOP PROG 1	Turn-off time of the first programme	Time – OFF
03 – 03 – 04	MONDAY PROG 1	Reference days of the first programme	On/off
03 – 03 – 05	TUESDAY PROG 1		On/off
03 – 03 – 06	WEDNESDAY PROG 1		On/off
03 – 03 – 07	THURSDAY PROG 1		On/off
03 – 03 – 08	FRIDAY PROG 1		On/off
03 – 03 – 09	SATURDAY PROG 1		On/off
03 – 03 – 10	SUNDAY PROG 1		On/off

PROGRAMME 2			
MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 03 – 11	START PROG 2	Turn-on time of the second programme	Time – OFF
03 – 03 – 12	STOP PROG 2	Turn-off time of the second programme	Time – OFF
03 – 03 – 13	MONDAY PROG 2	Reference days of the second programme	On/off
03 – 03 – 14	TUESDAY PROG 2		On/off
03 – 03 – 15	WEDNESDAY PROG 2		On/off
03 – 03 – 16	THURSDAY PROG 2		On/off
03 – 03 – 17	FRIDAY PROG 2		On/off
03 – 03 – 18	SATURDAY PROG 2		On/off
03 – 03 – 19	SUNDAY PROG 2		On/off

PROGRAMME 3			
MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 03 – 20	START PROG 3	Turn-on time of the third programme	Time – OFF
03 – 03 – 21	STOP PROG 3	Turn-off time of the third programme	Time – OFF
03 – 03 – 22	MONDAY PROG 3	Reference days of the third programme	On/off
03 – 03 – 23	TUESDAY PROG 3		On/off
03 – 03 – 24	WEDNESDAY PROG 3		On/off
03 – 03 – 25	THURSDAY PROG 3		On/off
03 – 03 – 26	FRIDAY PROG 3		On/off
03 – 03 – 27	SATURDAY PROG 3		On/off
03 – 03 – 28	SUNDAY PROG 3		On/off

PROGRAMME 4			
MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 03 – 29	START PROG 4	Turn-on time of the fourth programme	Time – OFF
03 – 03 – 30	STOP PROG 4	Turn-off time of the fourth programme	Time – OFF
03 – 03 – 31	MONDAY PROG 4	Reference days of the fourth programme	On/off
03 – 03 – 32	TUESDAY PROG 4		On/off
03 – 03 – 33	WEDNESDAY PROG 4		On/off
03 – 03 – 34	THURSDAY PROG 4		On/off
03 – 03 – 35	FRIDAY PROG 4		On/off
03 – 03 – 36	SATURDAY PROG 4		On/off
03 – 03 – 37	SUNDAY PROG 4		On/off

Sub-menu 03 – 04 – week-end program

Enables/disables/sets the programmable timer's weekend functions (Saturday and Sunday).

MENU LEVEL	SELECTION	MEANING	POSSIBLE VALUES
03 – 04 – 01	WEEKEND TIMER	Enable/disable the weekend programme	ON – OFF
03 – 04 – 02	START 1st WEEKEND	Turn-on time of the first programme	Time – OFF
03 – 04 – 03	STOP 1st WEEKEND	Turn-off time of the first programme	Time – OFF
03 – 04 – 04	START 2nd WEEKEND	Turn-on time of the second programme	Time – OFF
03 – 04 – 05	STOP 2nd WEEKEND	Turn-off time of the second programme	Time – OFF

TIP: in order to avoid confusion and any undesired switching on/off operations, only activate a single programme at a time (daily, weekly or weekend programme).

Deactivate the daily program if you wish to use the weekly program instead. If you use the weekly program in programs 1, 2, 3 and 4, always keep the week-end program disabled.

Only enable week-end programming after disabling the weekly program.

Menu 04 – Choose language

Allows you to select the dialogue language from the available choices (Italian, English, French, German and Spanish).

Menu 05 – Acoustic alarm

Allows you to enable or disable the acoustic signal in the event of an alarm. The alarm signal is only available on the appliance board, and not on the external “Remote control”.

Menu 06 – Initial load

Enables pellet pre-loading for 180” when the appliance is switched off and cooled down. Start the function with button 1 and stop with button 4. This may be useful if the appliance is switched on after the tank has been completely emptied, or when it is filled for the first time. **Warning: once the operation has been completed, before switching on the appliance you should empty the accumulation of pellets deposited inside the brazier.**

Menu 07 – Fireplace status

It allows for viewing the instantaneous state of the appliance, by showing the state of the various devices connected to it. Several pages are displayed in succession. The data is reserved for Technical assistance Centre.

Menu 08 – Technical calibration

Allows you to access all data reserved for the Technical Assistance Centre. Access is protected by a password. Unauthorised access can cause serious damage to the equipment, to things and the environment as well as personal injuries.

Menu 09 – System type

Allows you to configure the appliance according to the type of system it has been connected to (see “[System configuration](#)”).

Menu 10 – Vacuum control

Allows for configuring the operation of an automatic loading system (if present) with an auxiliary tank.

Sub-menu 10 – 01 – Type of control

Allows for setting how to control the Vacuum’s activation.

SENS = with pellet reserve sensor.

Whenever the level of pellets in the primary tank falls below the minimum level sensor, the Vacuum function is activated regardless of the time.

TIME = with pre-defined time (possibility of switching it on at one or two daily times).
Whenever the clock detects the set time, the motor activates.

Sub-menu 10 – 02 – Time 1

With M10-01-Type of control = TIME, allows for setting the first daily time for the Vacuum's activation.

Sub-menu 10 – 03 – Time 2

With M10-01-Type of control = TIME, allows for setting the second daily time for the Vacuum's activation.


INITIAL START-UP

System configuration

Before commissioning the appliance it is advisable to choose which type of system it has been connected to, by accessing "Menu 09 – System type".


The available configurations are given here below:

PLUMBING LAYOUT "1" – Boiler connected to a heating system and (potentially) an external plate heat exchanger for the generation of DHW.




Plumbing layout 1 involves the connection of the boiler to a heating system (or centralised puffer) managed by one or more room thermostats. These are connected to the terminal provided inside the left technical compartment on the appliance. DHW generation, where required, will be achieved using a plate heat exchanger fitted externally to the boiler and controlled by a flow-switch. This is also connected to a terminal provided on the boiler. This serves to bring the appliance immediately to DHW output working mode and to switch a three-way motorised valve to give it priority.

PLUMBING LAYOUT “2” – Boiler with built-in instant DHW, connected to a heating system with an additional DHW generator.



Plumbing layout 2 involves the connection of the boiler with built-in instant DHW (prepared models only) to a heating system managed by one or more room thermostats. These are connected to the terminal provided inside the left technical compartment on the appliance. DHW generation is achieved via a mini storage tank built-into the appliance. It is recommended to fit an alternative generator in order to guarantee constant DHW in this type of system. Control of this combination is ensured by a three-way motorised valve connected to the pellet boiler. This allows the DHW generated by the pellet boiler to be used only when it is operational and at a suitable temperature.

PLUMBING LAYOUT “3” – Boiler connected to a heating system and DHW storage boiler.




Plumbing layout 3 involves the connection of the boiler to a heating system managed by one or more room thermostats. These are connected to the terminal provided inside the left technical compartment on the appliance. Any DHW

generation is achieved by a storage boiler fitted externally to the boiler. This is controlled by a temperature sensor connected to the appliance.

The three-way motorised valve, controlled by the pellet boiler, manages the heating of the system or boiler, giving priority to the latter.

Setting "Menu 01 – Select season" to SUMMER allows you to control the storage boiler only during the summer (with the heating system off).

PLUMBING LAYOUT "4" – Boiler connected to a centralised puffer controlled by a H₂O sensor connected to the boiler.



Plumbing layout 4 involves the connection of the boiler to a centralised puffer controlled by a temperature sensor connected to the appliance. The boiler therefore operates only at the set temperature of the centralised puffer ("SET PUFFER" can be set using keys 1 and 2). In this type of system there are no room thermostats or three-way valves connected to the pellet boiler.

Filling the system for the first time

After the water connection of the appliance, fill the system as follows:

- Check the seal of all piping, the expansion vessel, and the circulation pump;
- Open the "automatic air release valve" on the appliance;
- Open the system load cock (mounted on the appliance) to load the system. Gradually allow the air to come out from the appliance through the "automatic air release valve"; **optimum working pressure is 1.5 bar (when the appliance is operating)**;
- Vent all radiators and any other de-aeration systems to ensure that there are no air bubbles in the system.

After installation, check the seal of all plumbing joints for the first few days of operation.

The system and the water inside the boiler can be emptied by opening the "boiler body and system drain cock" situated on the right side of the appliance.

In intensely cold periods it is good practice to leave the heating system running. In the event of a prolonged absence, anti-freeze must be added to the heating water or the system must be completely emptied.

In a system subject to being emptied frequently, it is essential that filling is performed with water suitably treated to remove hardness which can give rise to scaling.

Pellet loading and connection to the mains power supply

Perform the following operations:

- Connect the appliance to the electrical system by using the provided cable;
- Set the “power ON/OFF switch” on the front of the appliance to “I” (on);
- Fill the pellet tank; for the first ever ignition, to avoid wasting the time required for filling the entire screw feed channel **(this should be done every time the appliance runs out of pellets)**, we recommend you follow the instructions in the “Menu 08 – Initial load”;
- Switch the appliance on by using the ignition button on the display (button 4). See the instructions below. **Warning: before switching on the device make sure that there are no pellets in the brazier; otherwise it is necessary to empty and clean the brazier.**

We recommend that you use high quality pellets so as not to impair the operation of the appliance. Damage caused by poor-quality pellets shall not be covered by the warranty.

Do not pour pellets directly into the brazier.

Ignition cycle

Pressing button 4 (ON/OFF) for a few seconds allows you to start the ignition cycle. After a while, the display shows “**START**”, and the flue gas intake device and ignition plug switch on. After a few seconds, the appliance enters a pre-load phase “**PELLET P-LOAD**” during which a continuous supply of pellets is loaded. After the pre-loading phase the appliance switches to the “**WAITING FLAME**” phase where the pellets are loaded into the brazier at regular intervals. When the flame is lit, the display shows the message “**FIRE**”. This step is used to allow the fire to spread evenly across the brazier and burn all the unburned pellets from the previous phases. After these phases, the appliance enters the work mode at the pre-set power value.

If the ignition fails, the display will show the alarm “**NO IGNITION**”. **The alarm may also occur if the brazier is dirty; in this case, clean the brazier and re-start.**

Summary:

The ignition cycle can last 20/25 minutes max. and is divided into five steps:

- | | |
|-----------------------------|--|
| Step 1 - START | = Ignition of the flue gas extractor. |
| Step 2 - WAITING PREHEATING | = Waiting for the plug preheating. (Not as standard settings). |
| Step 3 - PELLETT P-LOAD | = Pellet pre-load (initial continuous load) and plug ignition. |
| Step 4 - WAITING FLAME | = Loading pellets (intermittent load) and plug operating. |
| Step 5 - FIRE | = Plug switch-off and flame stabilisation. |

The appliance switches into working mode after ignition phase at the power output set during ignition via buttons 1 and 2.

Warning: during the ignition phase and normal operation of the appliance, maintain the necessary safety distance and do not stand in front of it.


Switch-off cycle

The appliance switches off if you press button 4 (ON/OFF) during normal operation. The display will show “**FINAL CLEANING**”. The pellet loading stops and the flue gas extractor speed increases to maximum and then switches off after the cooling of the appliance, displaying “**OFF**”.

If button 4 (ON/OFF) is pressed during the ignition cycle, the appliance switches to “**WAITING OFF**” and the appliance will be turned off only at the end of the entire cycle; if, however, button 4 (ON/OFF) is pressed by mistake during this phase, you only need to press it again to delete “**WAITING OFF**”: the appliance will return to normal operation at the end of the entire ignition cycle.

Modifying the working power

To modify the maximum working power you must select “*SET POWER*” by pressing buttons 5 or 6. Press buttons 5 and 6 to change the setting. During this operation, the display will appear as in the following picture.




After setting the desired value, press button 4 or wait a few seconds to confirm.

Changing the water temperature boiler or puffer

- Boiler Water Temperature

For system types 1, 2 and 3, to modify the boiler water temperature, simply select “*SET H2O*” by pressing button 2. Now use buttons 1 and 2. During this operation, the display will appear as in the following picture.




After setting the desired value, press button 4 or wait a few seconds to confirm.

During the working mode the appliance enters “*Economy mode operation*” when that temperature value is reached.

- DHW storage boiler temperature

For system type 3, to modify the boiler temperature, simply select “*SET BOILER*” by pressing button 1. Now use buttons 1 and 2. During this operation, the display will appear as in the following picture.



After setting the desired value, press button 4 or wait a few seconds.


During the working phase, if the boiler is in demand the appliance will switch to “*Economy mode*” if $T.H2O > SET\ BOILER + 10^{\circ}C$.

Here below are the operating modes in the event that the “*SET BOILER*” temperature is reached:

- “Menu 01 – Select season = SUMMER” the appliance will immediately go into stand-by “STOP FLAME”.
- “Menu 01 – Select season = WINTER” the motorised three-way valve and the appliance will go into stand-by “STOP FLAME” only if the conditions in the heating system are satisfied.

- Puffer temperature

For system type 4, to modify the puffer temperature, simply select “SET PUFFER” by pressing buttons 1 or 2. Now use buttons 1 and 2. During this operation, the display will appear as in the following picture.



After setting the desired value, press button 4 or wait a few seconds.

During the working phase the appliance will switch to “Economy mode” if $T.H_2O > SET PUFFER + 10^{\circ}C$.

It will go into stand-by “STOP FLAME” only if the “SET PUFFER” temperature is reached.

PROBLEMS, ALARMS, USEFUL ADVICES

Useful info...

Listed below is some important information regarding the appliance:

- It is normal for the appliance to emit a smell of paint during its first few days of operation. We recommend ventilating the installation room during the initial start-up. For the first few days of operation we also recommend that you set the appliance to near-maximum level.
- The boiler unit is treated with anti-oxidant paint in order to protect it against oxidation in the event of long periods of inactivity. After initial start-up, this paint no longer preserves its original features and any wear of the paint inside the combustion chamber should not be regarded as a manufacturing fault.
- Do not clean with water inside the combustion chamber; any oxidation of the combustion chamber after a long period of inactivity is not to be considered as a manufacturing fault.
- Any perceived noise during operation may be caused by the expansion settling of the plates that make up the boiler unit. These noises are accentuated especially during ignition and switching off phases of the appliance and are not to be considered a manufacturing fault.
- **If ignition fails, empty the pellets out of the brazier; only then can you reignite the appliance in order to avoid gasification and consequent “explosion” during ignition which could lead to the breakage of the door glass.**
- The appliance works exclusively with wooden pellets; do not burn different fuels.
- The appliance can work only if connected to the heating system and with water inside the boiler unit. Do not start the appliance for any reason if a plumbing connection in compliance with current regulations has not been done and if you have not filled the entire boiler unit and system with water in order not to compromise its life.
- The noise heard during the ignition stage is due to the automatic cleaning of the turbulators.
- The noise level of the appliance is emphasised if the pellet container is empty. Therefore we recommend that you always keep the pellet level to at least half tank.
- If there is soot and fine particulate in the room where the appliance is installed, check the seal on the flue gas pipes and the filter of the ash vacuum device used for cleaning.
- In the event of overheating, the appliance will switch off when it reaches $85^{\circ}C$.

What happens if...

...the pellets do not ignite

If the ignition fails, the display will show the alarm message “NO IGNITION”.

Cancel the alarm and reset the appliance to standard condition by pressing button 4 for a few seconds.

If ignition fails, empty the pellets out of the brazier; to avoid gasification, the appliance can only be re-ignited after having emptied the un-burnt pellets.

...the fire door or the pellet container door is open or not properly closed

If the door is left open or not properly closed, the pellet loading will not start, therefore the appliance will not switch itself on. If the door is opened during normal operation, the appliance switches to "THERMAL SAFETY" alarm.

...the flue pipe is dirty, blocked or not correctly installed

If the flue is dirty, blocked or incorrectly manufactured, pellet loading will not start, thus the appliance will not switch itself on. If the flue is obstructed during normal operation, the appliance switches to "DEPRESS.-FAILURE" alarm.

...the appliance is overheated

If the water in the boiler body is overheated (>94°C), the pellet will not be loaded because the manual reset thermostat cuts in. If this happens during normal operation, the appliance switches to "THERMAL SAFETY" alarm. It is therefore necessary to reset the "manual reset thermostat" (see "Components of the appliance") before switching the appliance on again. To reset, it is necessary to remove the black cap and press the button below.

...lack of power (blackout)

If a power blackout occurs for a shorter time than Pr48, when power is restored, the appliance will immediately re-start in the working mode (recovering the set working power).

If the outage lasts longer than Pr48, when power is restored, the appliance will enter the "STOP FIRE" (stand-by) mode running the entire switch-off cycle until cooling. When this phase is over, the appliance can be restarted resuming work at the set power.

Previous state	Black-out duration	State after power restore
OFF	any	OFF
START	duration < Pr48	START
START	duration > Pr48	START
P-LOAD PELLETT	any	BLACK OUT ALARM
FLAME STAND-BY	any	BLACK OUT ALARM
FIRE PRESENT	duration < Pr48	FIRE PRESENT
FIRE PRESENT	duration > Pr48	STOP FIRE with automatic re-ignition after machine cooling
WORK (any phase)	duration < Pr48	WORK (any phase)
WORK (any phase)	duration > Pr48	STOP FIRE with automatic re-ignition after machine cooling
BRAZIER CLEANING	duration < Pr48	BRAZIER CLEANING
BRAZIER CLEANING	duration > Pr48	STOP FIRE with automatic re-ignition after machine cooling
FINAL CLEANING	duration < Pr48	FINAL CLEANING and after cooling → OFF
FINAL CLEANING	duration > Pr48	FINAL CLEANING and after cooling → OFF
STOP FIRE	any	STOP FIRE

Alarm signals

The following table describes the different alarms which may appear.

DISPLAY VISUALISATION	ORIGIN OF ALARM
AL 1 - BLACK OUT ACTIVE ALARM	Black-out alarm. When power is cut off under determined conditions (see "What happens if...")
AL 2 - FLUE GAS PROBE ACTIVE ALARM	Faulty or disconnected flue gas temperature sensor.
AL 3 - HOT TEMP ACTIVE ALARM	Flue gas over-temperature. Before displaying the alarm, or when flue gas maximum temperature is reached (Pr14), the display shows "HOT FLUE GAS".
AL 4 - EXTRACTOR-FAILURE ACTIVE ALARM	Faulty flue gas extractor. When the encoder (tachometer) in the extractor detects an extractor speed equal to 0.
AL 5 - NO IGNITION ACTIVE ALARM	No ignition. When the flue gas minimum temperature (Pr13) is not reached within the maximum ignition cycle time (Pr01).

AL 6 - NO PELLETT ACTIVE ALARM	Sudden shut-down during the work phase. When, during the work phase, the flue gas temperature drops below the minimum threshold (Pr28).
AL 7 - THERMAL-SAFETY ACTIVE ALARM	Temperature safety device. When the safety thermostat (water over temperature) or one of the micro switches (contact interrupted) fitted in the fire door or pellet container door cuts in. If the safety thermostat cuts in the boiler stove must be manually rearmed.
AL 8 - DEPRESS.-FAILURE ACTIVE ALARM	Poor depression. When the flue gas pressure switch cuts in (contact interrupted) due to poor draught in the flue pipe.
AL 9 - WATER PROBE ACTIVE ALARM	Faulty or disconnected water temperature probe.
AL c - SF TRIAC ERROR ACTIVE ALARM	Screw feed TRIAC error. When the screw feed gear motor does not stop for at least 0.2 seconds during the maximum work interval of 8.0 seconds. Before the alarm is activated a safety relay cuts in and forcibly cuts off the power supply to the gear motor.

Every alarm causes the appliance to switch-off immediately. The alarm state is reached after the time set on Pr11 (set as default at 60") and it can be reset by pressing button 4 for a while.

CLEANING AND MAINTENANCE

Precautions before cleaning

Before carrying out any cleaning or maintenance operations, make sure that:

- the appliance is off and has cooled down completely;
- the ash is completely cold.
- the ash vacuum device used for cleaning is suitable and its filter is in good condition.

Before re-starting the appliance, re-install all previously removed components.

During cleaning operations, use the personal protection devices specified in Directive 89/391/EEC.

The frequency for cleaning depends on the type and quality of pellet burnt; therefore, the indicated times may change.

Any problem affecting the appliance caused by lack of cleaning will not be covered by the warranty. The failure of these operations could affect the safety of the product.

Cleaning operations may be carried out by the end user, as indicated in the paragraph below.

Routine cleaning

The routine cleaning of the appliance must be done at least every 10 days of operation or after 20 ignition cycles, so as to always guarantee efficient performance and optimal operation. Please proceed as follows:



Empty the ash drawer (Figure 1).



Thoroughly clean the brazier from combustion residues by taking it out from its position and removing any residues inside (Figure 2). Use a suitable ash vacuum device to remove any ash deposited under the brazier (Figure 3).

To remove any deposits, it is also recommended that you scrape the inner walls of the combustion chamber with a spatula. Do not use tools that can reduce the thickness of the metal sheet of the boiler unit.

WARNING: use suitable ash vacuum devices equipped with a fine mesh filter in order to prevent ash from being blown into the room and to prevent damaging the vacuum cleaner. We do not recommend the use of normal vacuum cleaners.


Non-routine cleaning

The extraordinary cleaning of the appliance must be done at least every 90 days so as to always guarantee efficient performance and optimal operation. Please proceed as follows:

Perform routine cleaning;



Remove the “extractor flue gas pass inspection front plate” by unscrewing the 4 screws (figure 4).
Using the ash vacuum, vacuum the deposit inside (figure 5).



Remove the front guard (figures 6 and 7).



After removing the turbulator inspection front plate (Figure 8), vacuum the deposits on the inside using a suitable ash vacuum device (Figure 9). When finished, replace the plate and front guard.



To ensure correct operation, it is necessary to remove the sawdust deposited on the base of the tank (Figure 10) at least once every 30 days. **The pellet tank must be emptied at the end of every season.**

Cleaning the ceramic glass

Always clean the glass when the appliance is off and has cooled down completely. Use a damp cloth or a detergent specifically formulated for ceramic glass. Do not use abrasive sponges. Do not clean the glass if still warm; changes in temperature can lead to breakage.

Cleaning the flue

The flue must be cleaned at least once a year, at the beginning of winter, and whenever it becomes necessary. It is important to check for any obstructions in the flue before switching the appliance on following long periods of inactivity.

If the flue is not cleaned, the operation of the appliance and its components may be compromised.

The cleaning frequency of the appliance and flue depends on the quality of the pellets used.

USE TOP QUALITY PELLETS TO OBTAIN THE BEST RESULTS.

Maintenance

Timely and systematic maintenance is essential for guaranteeing correct operation, optimal heat performance and durability of the device. Therefore, qualified staff should check the appliance at least once a year at the beginning of the season.

You must periodically check the seals because the latter guarantee the air- and water-tightness of the appliance and its good functioning; if they are worn or damaged you need to be replace them immediately by contacting a ***Klover Authorised technical assistance centre***.

For proper operation, the appliance must undergo routine maintenance performed by a *Klover Authorised technical assistance centre* at least once a year.

PCB PARAMETERS

The parameters stored on the PCB are essential for the correct operation.

The following parameters are already stored during the testing of the appliance directly in the factory; these parameters are the result of special tests using several types of pellets and must not be changed without the authorisation of Klover srl so as not to impair the operation of the appliance.

The company shall not be held liable for any damage caused by the incorrect entry of parameters.

Parameter tables ECOMPACT 150

Parameters "VARIOUS CALIBRATIONS" - Mod. ECO150 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database M0
Pr38	M08 - 4 - 01	Re-ignition block	RE-IGNIT BLOCK	Minutes	0 - 10	6
Pr39	M08 - 4 - 02	Flue gas extractor switch-off time	MIN-EXT OFF	Minutes	0 - 20	10
Pr40	M08 - 4 - 03	Pre-loading time in ignition	IGNIT- PRE-LOAD	Seconds	0 - 255	120
Pr41	M08 - 4 - 04	Stand-by time after pre-loading	AFTER-PRE STAND-BY	Seconds	0 - 255	60
Pr42	M08 - 4 - 05	Extractor speed in pre-loading phase	FLUE GAS-EXT PRELOAD	RPM	350 - 2800	2200
Pr43	M08 - 4 - 06	ON/OFF temperature hysteresis on "SET H2O"	DELTA ON OFF AUTO	°C	0.0 - 20.0	5.0
Pr44	M08 - 4 - 07	Delay at economy operation mode switch-off (timer after reaching "SET H2O")	DELAY-OFF AUTO	Minutes	2 - 120	20
Pr45	M08 - 4 - 08	Power change delay	POWER CHANGE	Seconds	0 - 60	20
Pr46	M08 - 4 - 09	ON/OFF Temperature hysteresis on "SET ROOM"	DELTA ON AUTO	°C	0.0 - 15.0	2.0
Pr47	M08 - 4 - 10	Keypad lock enable	KEY LOCK-EN	On - off	On - off	Off
Pr48	M08 - 4 - 11	Time after which an alarm is triggered in the event of a blackout	BLACKOUT ALARM	Seconds	0 - 60	30
Pr49	M08 - 4 - 12	Pellet level sensor enable	PELLET RESERVE	On - off	On - off	On
Pr50	M08 - 4 - 13	Pump start threshold and power modulation for overheating safety	PUMP SAFETY	°C	60 - 90	80
Pr51	M08 - 4 - 14	3-way switching and re-ignition delta on "SET BOILER" and "SET PUFFER"	DELTA PUF-BOI	°C	0 - 15	5
Pr52	M08 - 4 - 15	Preheating time	PREHEATING TIME	Seconds	0 - 480	0
Pr53	M08 - 4 - 16	Extractor speed in preheating phase	PREHEAT-F.GAS-SPEED	RPM	500 - 2800	2800
Pr54	M08 - 4 - 17	Time after which the "NO PELLETS" alarm is triggered if "PELLET RESERVE"	RESERVE ALARM	Minutes	1 - 180	40
Pr55	M08 - 4 - 18	ON time for turbulator cleaning gear motor	TURBOLAT DURATION	Seconds	0 - 600"	120
Pr56	M08 - 4 - 19	ON time for brazier cleaning gear motor (NOT USED)	CLEANING TIME	Seconds	0 - 120"	0
Pr57	M08 - 4 - 20	Time from switching OFF after which the brazier cleaning takes place (NOT USED)	CLEANER DELAY	Minutes	1 - 15'	1
Pr58	M08 - 4 - 21	Time from switching ON after which the brazier cleaning takes place (NOT USED)	CLEANER STAND-BY	Hours	1 - 24	24
Pr59	M08 - 4 - 22	Pump activation threshold and switching 3-way valve in DHW OUTPUT MODE (with Type 2 System)	PUMP THRESHOLD I2	°C	55 - 75	60

Parameters "VACUUM CALIBRATIONS" - Mod. ECO150 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database M0
Pr133	M08 - A - 01	Enable automatic pellet loading vacuum	ENABLE VACUUM	On - off	On - Off	On
Pr134	M08 - A - 02	Vacuum on time	VACUUM ACTIVE	Seconds	1 - 180	15
Pr135	M08 - A - 03	Enables a Vacuum operating test to be performed	VACUUM TEST	On - off	On - off	Off

Parameters "FACTORY CALIBRATIONS" - Mod. ECO150 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database M0
Pr01	M08 - 6 - 01	Ignition cycle maximum time	IGNIT- MINUTES	Minutes	5 - 25	18
Pr02	M08 - 6 - 02	Start time	START MINUTES	Minutes	2 - 12	7
Pr03	M08 - 6 - 03	Time interval between the two brazier cleaning operations	BRAZIER CLEANING	Minutes	3 - 240	60
Pr04	M08 - 6 - 04	Screw feed gear motor ON time in ignition phase	IGNIT- SCREW FEED	Seconds	0.1 - 8.0	2,0

Pr05	M08 – 6 – 05	Screw feed gear motor ON time in start phase	SCREW FEED START	Seconds	0.1 – 8.0	1,5
Pr06	M08 – 6 – 06	Screw feed gear motor ON time in power 1 work phase	OUTPUT 1 SCREW FEED	Seconds	0.1 – 8.0	3,4
Pr07	M08 – 6 – 07	Screw feed gear motor ON time in power 2 work phase	OUTPUT 2 SCREW FEED	Seconds	0.1 – 8.0	4,0
Pr08	M08 – 6 – 08	Screw feed gear motor ON time in power 3 work phase	OUTPUT 3 SCREW FEED	Seconds	0.1 – 8.0	4,8
Pr09	M08 – 6 – 09	Screw feed gear motor ON time in power 4 work phase	OUTPUT 4 SCREW FEED	Seconds	0.1 – 8.0	5,4
Pr10	M08 – 6 – 10	Screw feed gear motor ON time in power 5 work phase	OUTPUT 5 SCREW FEED	Seconds	0.1 – 8.0	6,2
Pr11	M08 – 6 – 11	Alarm delay	ALARM DELAY	Seconds	0 – 120	90
Pr12	M08 – 6 – 12	Brazier cleaning duration	BRAZIER CLEANING	Seconds	0 – 120	50
Pr13	M08 – 6 – 13	Flue gas minimum temperature for considering the stove on	MINIMUM THRESHOLD	°C	40 – 600	180
Pr14	M08 – 6 – 14	Flue gas maximum temperature	MAXIMUM THRESHOLD	°C	200 – 880	880
Pr15	M08 – 6 – 15	Flue gas temperature threshold for the air exchanger start-up (NOT USED)	FAN THRESHOLD	°C	200 – 720	720
Pr16	M08 – 6 – 16	Flue gas extraction speed in ignition phase	IGNIT FLUE GAS SPEED	RPM	500 – 2800	2000
Pr17	M08 – 6 – 17	Flue gas extraction speed in start phase	START FLUE GAS SPEED	RPM	500 – 2800	1800
Pr18	M08 – 6 – 18	Flue gas extraction speed in power 1 work phase	P 1 FLUE GAS SPEED	RPM	500 – 2800	1500
Pr19	M08 – 6 – 19	Flue gas extraction speed in power 2 work phase	P 2 FLUE GAS SPEED	RPM	500 – 2800	1650
Pr20	M08 – 6 – 20	Flue gas extraction speed in power 3 work phase	P 3 FLUE GAS SPEED	RPM	500 – 2800	1750
Pr21	M08 – 6 – 21	Flue gas extraction speed in power 4 work phase	P 4 FLUE GAS SPEED	RPM	500 – 2800	1900
Pr22	M08 – 6 – 22	Flue gas extraction speed in power 5 work phase	P 5 FLUE GAS SPEED	RPM	500 – 2800	2100
Pr23	M08 – 6 – 23	Exchanger 1 motor speed in output 1 working mode (NOT USED)	AIR 1 SPEED	Volt	65 – 225	65
Pr24	M08 – 6 – 24	Exchanger 1 motor speed in output 2 working mode (NOT USED)	AIR 2 SPEED	Volt	65 – 225	65
Pr25	M08 – 6 – 25	Exchanger 1 motor speed in output 3 working mode (NOT USED)	AIR 3 SPEED	Volt	65 – 225	65
Pr26	M08 – 6 – 26	Exchanger 1 motor speed in output 4 working mode (NOT USED)	AIR 4 SPEED	Volt	65 – 225	65
Pr27	M08 – 6 – 27	Exchanger 1 motor speed in output 5 working mode (NOT USED)	AIR 5 SPEED	Volt	65 – 225	65
Pr28	M08 – 6 – 28	Threshold beneath which the appliance is considered to be OFF	THRESHOLD OFF	°C	80 – 600	140
Pr29	M08 – 6 – 29	Flue gas extraction speed in brazier cleaning phase	FLUE GAS-EXT CLEANING	RPM	500 – 2800	2800
Pr30	M08 – 6 – 30	Screw feed gear motor ON time in cleaning phase	CLEANING SCREW FEED	Seconds	0.0 – 8.0	2,0
Pr31	M08 – 6 – 31	Flue gas extractor encoder enable (NOT USED)	ENCODER	On – off	On – Off	On
Pr32	M08 – 6 – 32	Screw feed brake time	BRAKE TIME	Seconds	0.0 – 0.5	0,2
Pr33	M08 – 6 – 33	Pump activation threshold	PUMP THRESHOLD	°C	20 – 70	55
Pr34	M08 – 6 – 34	Water pressure switch enable (NOT USED)	WATER PRESSURESW.	On – off	On – Off	On
Pr35	M08 – 6 – 35	Water pressure threshold (NOT USED)	PRESSURE THRESHOLD	Bar	1.5 – 3.0	2,5
Pr36	M08 – 6 – 36	Screw feed motor reducer ON time in DHW output working mode	DHW SCREW FEED	Seconds	0.1 – 8.0	6,2
Pr37	M08 – 6 – 37	Flue gas intake speed in DHW output working mode	DHW FLUE GAS-INTAKE DEVICE	RPM	500 – 2800	2100

Parameter tables ECOMPACT 190

Parameters "VARIOUS CALIBRATIONS" - Mod. ECO190 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database n0
Pr38	M08 – 4 – 01	Re-ignition block	RE-IGNIT BLOCK	Minutes	0 – 10	6
Pr39	M08 – 4 – 02	Flue gas extractor switch-off time	MIN-EXT OFF	Minutes	0 – 20	10
Pr40	M08 – 4 – 03	Pre-loading time in ignition	IGNIT- PRE-LOAD	Seconds	0 – 255	70
Pr41	M08 – 4 – 04	Stand-by time after pre-loading	AFTER-PRE STAND-BY	Seconds	0 – 255	60
Pr42	M08 – 4 – 05	Extractor speed in pre-loading phase	FLUE GAS-EXT PRELOAD	RPM	350 – 2800	2200
Pr43	M08 – 4 – 06	ON/OFF temperature hysteresis on "SET H2O"	DELTA ON OFF AUTO	°C	0.0 – 20.0	5.0
Pr44	M08 – 4 – 07	Delay at economy operation mode switch-off (timer after reaching "SET H2O")	DELAY-OFF AUTO	Minutes	2 – 120	20
Pr45	M08 – 4 – 08	Power change delay	POWER CHANGE	Seconds	0 – 60	20
Pr46	M08 – 4 – 09	ON/OFF Temperature hysteresis on "SET ROOM"	DELTA ON AUTO	°C	0.0 – 15.0	2.0
Pr47	M08 – 4 – 10	Keypad lock enable	KEY LOCK-EN	On – off	On – off	Off
Pr48	M08 – 4 – 11	Time after which an alarm is triggered in the event of a blackout	BLACKOUT ALARM	Seconds	0 – 60	30
Pr49	M08 – 4 – 12	Pellet level sensor enable	PELLET RESERVE	On – off	On – off	On
Pr50	M08 – 4 – 13	Pump start threshold and power modulation for overheating safety	PUMP SAFETY	°C	60 – 90	80
Pr51	M08 – 4 – 14	3-way switching and re-ignition delta on "SET BOILER" and "SET PUFFER"	DELTA PUF-BOI	°C	0 – 15	5
Pr52	M08 – 4 – 15	Preheating time	PREHEATING TIME	Seconds	0 – 480	0
Pr53	M08 – 4 – 16	Extractor speed in preheating phase	PREHEAT-F.GAS-SPEED	RPM	500 – 2800	2800
Pr54	M08 – 4 – 17	Time after which the "NO PELLETT" alarm is triggered if "PELLET RESERVE"	RESERVE ALARM	Minutes	1 – 180	40
Pr55	M08 – 4 – 18	ON time for turbulator cleaning gear motor	TURBOLAT DURATION	Seconds	0 – 600"	120
Pr56	M08 – 4 – 19	ON time for brazier cleaning gear motor (NOT USED)	CLEANING TIME	Seconds	0 – 120"	0
Pr57	M08 – 4 – 20	Time from switching off after which the brazier cleaning takes place (NOT USED)	CLEANER DELAY	Minutes	1 – 15'	1
Pr58	M08 – 4 – 21	Time from switching ON after which the brazier cleaning takes place (NOT USED)	CLEANER STAND-BY	Hours	1 – 24	24
Pr59	M08 – 4 – 22	Pump activation threshold and switching 3-way valve in DHW OUTPUT MODE (with Type 2 System)	PUMP THRESHOLD I2	°C	55 – 75	60

Parameters "VACUUM CALIBRATIONS" - Mod. ECO190 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database n0
Pr133	M08 – A – 01	Enable automatic pellet loading vacuum	ENABLE VACUUM	On – off	On – Off	On
Pr134	M08 – A – 02	Vacuum on time	VACUUM ACTIVE	Seconds	1 – 180	15
Pr135	M08 – A – 03	Enables a Vacuum operating test to be performed	VACUUM TEST	On – off	On – off	Off

Parameters "FACTORY CALIBRATIONS" - Mod. ECO190 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database n0
Pr01	M08 – 6 – 01	Ignition cycle maximum time	IGNIT- MINUTES	Minutes	5 – 25	18
Pr02	M08 – 6 – 02	Start time	START MINUTES	Minutes	2 – 12	7
Pr03	M08 – 6 – 03	Time interval between the two brazier cleaning operations	BRAZIER CLEANING	Minutes	3 – 240	60
Pr04	M08 – 6 – 04	Screw feed gear motor ON time in ignition phase	IGNIT- SCREW FEED	Seconds	0.1 – 8.0	0,9
Pr05	M08 – 6 – 05	Screw feed gear motor ON time in start phase	SCREW FEED START	Seconds	0.1 – 8.0	1,4
Pr06	M08 – 6 – 06	Screw feed gear motor ON time in power 1 work phase	OUTPUT 1 SCREW FEED	Seconds	0.1 – 8.0	2,4
Pr07	M08 – 6 – 07	Screw feed gear motor ON time in power 2 work phase	OUTPUT 2 SCREW FEED	Seconds	0.1 – 8.0	3,0
Pr08	M08 – 6 – 08	Screw feed gear motor ON time in power 3 work phase	OUTPUT 3 SCREW FEED	Seconds	0.1 – 8.0	3,8
Pr09	M08 – 6 – 09	Screw feed gear motor ON time in power 4 work phase	OUTPUT 4 SCREW FEED	Seconds	0.1 – 8.0	4,6

Pr10	M08 – 6 – 10	Screw feed gear motor ON time in power 5 work phase	OUTPUT 5 SCREW FEED	Seconds	0.1 – 8.0	5,2
Pr11	M08 – 6 – 11	Alarm delay	ALARM DELAY	Seconds	0 – 120	90
Pr12	M08 – 6 – 12	Brazier cleaning duration	BRAZIER CLEANING	Seconds	0 – 120	50
Pr13	M08 – 6 – 13	Flue gas minimum temperature for considering the stove on	MINIMUM THRESHOLD	°C	40 – 600	180
Pr14	M08 – 6 – 14	Flue gas maximum temperature	MAXIMUM THRESHOLD	°C	200 – 880	880
Pr15	M08 – 6 – 15	Flue gas temperature threshold for the air exchanger start-up (NOT USED)	FAN THRESHOLD	°C	200 – 720	720
Pr16	M08 – 6 – 16	Flue gas extraction speed in ignition phase	IGNIT FLUE GAS SPEED	RPM	500 – 2800	2000
Pr17	M08 – 6 – 17	Flue gas extraction speed in start phase	START FLUE GAS SPEED	RPM	500 – 2800	1800
Pr18	M08 – 6 – 18	Flue gas extraction speed in power 1 work phase	P 1 FLUE GAS SPEED	RPM	500 – 2800	1550
Pr19	M08 – 6 – 19	Flue gas extraction speed in power 2 work phase	P 2 FLUE GAS SPEED	RPM	500 – 2800	1700
Pr20	M08 – 6 – 20	Flue gas extraction speed in power 3 work phase	P 3 FLUE GAS SPEED	RPM	500 – 2800	1850
Pr21	M08 – 6 – 21	Flue gas extraction speed in power 4 work phase	P 4 FLUE GAS SPEED	RPM	500 – 2800	2050
Pr22	M08 – 6 – 22	Flue gas extraction speed in power 5 work phase	P 5 FLUE GAS SPEED	RPM	500 – 2800	2200
Pr23	M08 – 6 – 23	Exchanger 1 motor speed in output 1 working mode (NOT USED)	AIR 1 SPEED	Volt	65 – 225	65
Pr24	M08 – 6 – 24	Exchanger 1 motor speed in output 2 working mode (NOT USED)	AIR 2 SPEED	Volt	65 – 225	65
Pr25	M08 – 6 – 25	Exchanger 1 motor speed in output 3 working mode (NOT USED)	AIR 3 SPEED	Volt	65 – 225	65
Pr26	M08 – 6 – 26	Exchanger 1 motor speed in output 4 working mode (NOT USED)	AIR 4 SPEED	Volt	65 – 225	65
Pr27	M08 – 6 – 27	Exchanger 1 motor speed in output 5 working mode (NOT USED)	AIR 5 SPEED	Volt	65 – 225	65
Pr28	M08 – 6 – 28	Threshold beneath which the appliance is considered to be OFF	THRESHOLD OFF	°C	80 – 600	140
Pr29	M08 – 6 – 29	Flue gas extraction speed in brazier cleaning phase	FLUE GAS-EXT CLEANING	RPM	500 – 2800	2800
Pr30	M08 – 6 – 30	Screw feed gear motor ON time in cleaning phase	CLEANING SCREW FEED	Seconds	0.0 – 8.0	1,8
Pr31	M08 – 6 – 31	Flue gas extractor encoder enable (NOT USED)	ENCODER	On – off	On – Off	On
Pr32	M08 – 6 – 32	Screw feed brake time	BRAKE TIME	Seconds	0.0 – 0.5	0,2
Pr33	M08 – 6 – 33	Pump activation threshold	PUMP THRESHOLD	°C	20 – 70	55
Pr34	M08 – 6 – 34	Water pressure switch enable (NOT USED)	WATER PRESSURESW.	On – off	On – Off	On
Pr35	M08 – 6 – 35	Water pressure threshold (NOT USED)	PRESSURE THRESHOLD	Bar	1.5 – 3.0	2,5
Pr36	M08 – 6 – 36	Screw feed motor reducer ON time in DHW output working mode	DHW SCREW FEED	Seconds	0.1 – 8.0	5,2
Pr37	M08 – 6 – 37	Flue gas intake speed in DHW output working mode	DHW FLUE GAS-INTAKE DEVICE	RPM	500 – 2800	2200

Parameter tables ECOMPACT 250

Parameters "VARIOUS CALIBRATIONS" - Mod. ECO250 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database P0
Pr38	M08 – 4 – 01	Re-ignition block	RE-IGNIT BLOCK	Minutes	0 – 10	6
Pr39	M08 – 4 – 02	Flue gas extractor switch-off time	MIN-EXT OFF	Minutes	0 – 20	10
Pr40	M08 – 4 – 03	Pre-loading time in ignition	IGNIT- PRE-LOAD	Seconds	0 – 255	90
Pr41	M08 – 4 – 04	Stand-by time after pre-loading	AFTER-PRE STAND-BY	Seconds	0 – 255	60
Pr42	M08 – 4 – 05	Extractor speed in pre-loading phase	FLUE GAS-EXT PRELOAD	RPM	350 – 2800	2100
Pr43	M08 – 4 – 06	ON/OFF temperature hysteresis on "SET H2O"	DELTA ON OFF AUTO	°C	0.0 – 20.0	5.0
Pr44	M08 – 4 – 07	Delay at economy operation mode switch-off (timer after reaching "SET H2O")	DELAY-OFF AUTO	Minutes	2 – 120	20
Pr45	M08 – 4 – 08	Power change delay	POWER CHANGE	Seconds	0 – 60	20
Pr46	M08 – 4 – 09	ON/OFF Temperature hysteresis on "SET ROOM"	DELTA ON AUTO	°C	0.0 – 15.0	2.0
Pr47	M08 – 4 – 10	Keypad lock enable	KEY LOCK-EN	On – off	On – off	Off
Pr48	M08 – 4 – 11	Time after which an alarm is triggered in the event of a blackout	BLACKOUT ALARM	Seconds	0 – 60	30
Pr49	M08 – 4 – 12	Pellet level sensor enable	PELLET RESERVE	On – off	On – off	On
Pr50	M08 – 4 – 13	Pump start threshold and power modulation for overheating safety	PUMP SAFETY	°C	60 – 90	80
Pr51	M08 – 4 – 14	3-way switching and re-ignition delta on "SET BOILER" and "SET PUFFER"	DELTA PUF-BOI	°C	0 – 15	5
Pr52	M08 – 4 – 15	Preheating time	PREHEATING TIME	Seconds	0 – 480	0
Pr53	M08 – 4 – 16	Extractor speed in preheating phase	PREHEAT-F.GAS-SPEED	RPM	500 – 2800	2800
Pr54	M08 – 4 – 17	Time after which the "NO PELLETT" alarm is triggered if "PELLET RESERVE"	RESERVE ALARM	Minutes	1 – 180	40
Pr55	M08 – 4 – 18	ON time for turbulator cleaning gear motor	TURBOLAT DURATION	Seconds	0 – 600"	120
Pr56	M08 – 4 – 19	ON time for brazier cleaning gear motor (NOT USED)	CLEANING TIME	Seconds	0 – 120"	0
Pr57	M08 – 4 – 20	Time from switching off after which the brazier cleaning takes place (NOT USED)	CLEANER DELAY	Minutes	1 – 15'	1
Pr58	M08 – 4 – 21	Time from switching ON after which the brazier cleaning takes place (NOT USED)	CLEANER STAND-BY	Hours	1 – 24	24
Pr59	M08 – 4 – 22	Pump activation threshold and switching 3-way valve in DHW OUTPUT MODE (with Type 2 System)	PUMP THRESHOLD I2	°C	55 – 75	60

Parameters "VACUUM CALIBRATIONS" - Mod. ECO250 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database P0
Pr133	M08 – A – 01	Enable automatic pellet loading vacuum	ENABLE VACUUM	On – off	On – Off	On
Pr134	M08 – A – 02	Vacuum on time	VACUUM ACTIVE	Seconds	1 – 180	25
Pr135	M08 – A – 03	Enables a Vacuum operating test to be performed	VACUUM TEST	On – off	On – off	Off

Parameters "FACTORY CALIBRATIONS" - Mod. ECO250 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database P0
Pr01	M08 – 6 – 01	Ignition cycle maximum time	IGNIT- MINUTES	Minutes	5 – 25	18
Pr02	M08 – 6 – 02	Start time	START MINUTES	Minutes	2 – 12	8
Pr03	M08 – 6 – 03	Time interval between the two brazier cleaning operations	BRAZIER CLEANING	Minutes	3 – 240	90
Pr04	M08 – 6 – 04	Screw feed gear motor ON time in ignition phase	IGNIT- SCREW FEED	Seconds	0.1 – 8.0	1,4
Pr05	M08 – 6 – 05	Screw feed gear motor ON time in start phase	SCREW FEED START	Seconds	0.1 – 8.0	1,2
Pr06	M08 – 6 – 06	Screw feed gear motor ON time in power 1 work phase	OUTPUT 1 SCREW FEED	Seconds	0.1 – 8.0	2,8
Pr07	M08 – 6 – 07	Screw feed gear motor ON time in power 2 work phase	OUTPUT 2 SCREW FEED	Seconds	0.1 – 8.0	4,0
Pr08	M08 – 6 – 08	Screw feed gear motor ON time in power 3 work phase	OUTPUT 3 SCREW FEED	Seconds	0.1 – 8.0	5,0
Pr09	M08 – 6 – 09	Screw feed gear motor ON time in power 4 work phase	OUTPUT 4 SCREW FEED	Seconds	0.1 – 8.0	6,2

Pr10	M08 – 6 – 10	Screw feed gear motor ON time in power 5 work phase	OUTPUT 5 SCREW FEED	Seconds	0.1 – 8.0	7,2
Pr11	M08 – 6 – 11	Alarm delay	ALARM DELAY	Seconds	0 – 120	90
Pr12	M08 – 6 – 12	Brazier cleaning duration	BRAZIER CLEANING	Seconds	0 – 120	40
Pr13	M08 – 6 – 13	Flue gas minimum temperature for considering the stove on	MINIMUM THRESHOLD	°C	40 – 600	180
Pr14	M08 – 6 – 14	Flue gas maximum temperature	MAXIMUM THRESHOLD	°C	200 – 880	880
Pr15	M08 – 6 – 15	Flue gas temperature threshold for the air exchanger start-up (NOT USED)	FAN THRESHOLD	°C	200 – 720	720
Pr16	M08 – 6 – 16	Flue gas extraction speed in ignition phase	IGNIT FLUE GAS SPEED	RPM	500 – 2800	1900
Pr17	M08 – 6 – 17	Flue gas extraction speed in start phase	START FLUE GAS SPEED	RPM	500 – 2800	1600
Pr18	M08 – 6 – 18	Flue gas extraction speed in power 1 work phase	P 1 FLUE GAS SPEED	RPM	500 – 2800	1400
Pr19	M08 – 6 – 19	Flue gas extraction speed in power 2 work phase	P 2 FLUE GAS SPEED	RPM	500 – 2800	1600
Pr20	M08 – 6 – 20	Flue gas extraction speed in power 3 work phase	P 3 FLUE GAS SPEED	RPM	500 – 2800	1700
Pr21	M08 – 6 – 21	Flue gas extraction speed in power 4 work phase	P 4 FLUE GAS SPEED	RPM	500 – 2800	1800
Pr22	M08 – 6 – 22	Flue gas extraction speed in power 5 work phase	P 5 FLUE GAS SPEED	RPM	500 – 2800	2000
Pr23	M08 – 6 – 23	Exchanger 1 motor speed in output 1 working mode (NOT USED)	AIR 1 SPEED	Volt	65 – 225	65
Pr24	M08 – 6 – 24	Exchanger 1 motor speed in output 2 working mode (NOT USED)	AIR 2 SPEED	Volt	65 – 225	65
Pr25	M08 – 6 – 25	Exchanger 1 motor speed in output 3 working mode (NOT USED)	AIR 3 SPEED	Volt	65 – 225	65
Pr26	M08 – 6 – 26	Exchanger 1 motor speed in output 4 working mode (NOT USED)	AIR 4 SPEED	Volt	65 – 225	65
Pr27	M08 – 6 – 27	Exchanger 1 motor speed in output 5 working mode (NOT USED)	AIR 5 SPEED	Volt	65 – 225	65
Pr28	M08 – 6 – 28	Threshold beneath which the appliance is considered to be OFF	THRESHOLD OFF	°C	80 – 600	140
Pr29	M08 – 6 – 29	Flue gas extraction speed in brazier cleaning phase	FLUE GAS-EXT CLEANING	RPM	500 – 2800	2600
Pr30	M08 – 6 – 30	Screw feed gear motor ON time in cleaning phase	CLEANING SCREW FEED	Seconds	0.0 – 8.0	2,0
Pr31	M08 – 6 – 31	Flue gas extractor encoder enable (NOT USED)	ENCODER	On – off	On – Off	On
Pr32	M08 – 6 – 32	Screw feed brake time	BRAKE TIME	Seconds	0.0 – 0.5	0,2
Pr33	M08 – 6 – 33	Pump activation threshold	PUMP THRESHOLD	°C	20 – 70	55
Pr34	M08 – 6 – 34	Water pressure switch enable (NOT USED)	WATER PRESSURESW.	On – off	On – Off	On
Pr35	M08 – 6 – 35	Water pressure threshold (NOT USED)	PRESSURE THRESHOLD	Bar	1.5 – 3.0	2,5
Pr36	M08 – 6 – 36	Screw feed motor reducer ON time in DHW output working mode	DHW SCREW FEED	Seconds	0.1 – 8.0	7,2
Pr37	M08 – 6 – 37	Flue gas intake speed in DHW output working mode	DHW FLUE GAS-INTAKE DEVICE	RPM	500 – 2800	2000

Parameter tables ECOMPACT 290


Parameters "VARIOUS CALIBRATIONS" - Mod. ECO290 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database o0
Pr38	M08 – 4 – 01	Re-ignition block	RE-IGNIT BLOCK	Minutes	0 – 10	6
Pr39	M08 – 4 – 02	Flue gas extractor switch-off time	MIN-EXT OFF	Minutes	0 – 20	10
Pr40	M08 – 4 – 03	Pre-loading time in ignition	IGNIT- PRE-LOAD	Seconds	0 – 255	70
Pr41	M08 – 4 – 04	Stand-by time after pre-loading	AFTER-PRE STAND-BY	Seconds	0 – 255	60
Pr42	M08 – 4 – 05	Extractor speed in pre-loading phase	FLUE GAS-EXT PRELOAD	RPM	350 – 2800	2100
Pr43	M08 – 4 – 06	ON/OFF temperature hysteresis on "SET H2O"	DELTA ON OFF AUTO	°C	0.0 – 20.0	5.0
Pr44	M08 – 4 – 07	Delay at economy operation mode switch-off (timer after reaching "SET H2O")	DELAY-OFF AUTO	Minutes	2 – 120	20
Pr45	M08 – 4 – 08	Power change delay	POWER CHANGE	Seconds	0 – 60	20
Pr46	M08 – 4 – 09	ON/OFF Temperature hysteresis on "SET ROOM"	DELTA ON AUTO	°C	0.0 – 15.0	2.0
Pr47	M08 – 4 – 10	Keypad lock enable	KEY LOCK-EN	On – off	On – off	Off
Pr48	M08 – 4 – 11	Time after which an alarm is triggered in the event of a blackout	BLACKOUT ALARM	Seconds	0 – 60	30
Pr49	M08 – 4 – 12	Pellet level sensor enable	PELLET RESERVE	On – off	On – off	On
Pr50	M08 – 4 – 13	Pump start threshold and power modulation for overheating safety	PUMP SAFETY	°C	60 – 90	80
Pr51	M08 – 4 – 14	3-way switching and re-ignition delta on "SET BOILER" and "SET PUFFER"	DELTA PUF-BOI	°C	0 – 15	5
Pr52	M08 – 4 – 15	Preheating time	PREHEATING TIME	Seconds	0 – 480	0
Pr53	M08 – 4 – 16	Extractor speed in preheating phase	PREHEAT-F.GAS-SPEED	RPM	500 – 2800	2800
Pr54	M08 – 4 – 17	Time after which the "NO PELLETT" alarm is triggered if "PELLET RESERVE"	RESERVE ALARM	Minutes	1 – 180	40
Pr55	M08 – 4 – 18	ON time for turbulator cleaning gear motor	TURBOLAT DURATION	Seconds	0 – 600"	120
Pr56	M08 – 4 – 19	ON time for brazier cleaning gear motor (NOT USED)	CLEANING TIME	Seconds	0 – 120"	0
Pr57	M08 – 4 – 20	Time from switching off after which the brazier cleaning takes place (NOT USED)	CLEANER DELAY	Minutes	1 – 15'	1
Pr58	M08 – 4 – 21	Time from switching ON after which the brazier cleaning takes place (NOT USED)	CLEANER STAND-BY	Hours	1 – 24	24
Pr59	M08 – 4 – 22	Pump activation threshold and switching 3-way valve in DHW OUTPUT MODE (with Type 2 System)	PUMP THRESHOLD I2	°C	55 – 75	60

Parameters "VACUUM CALIBRATIONS" - Mod. ECO290 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database o0
Pr133	M08 – A – 01	Enable automatic pellet loading vacuum	ENABLE VACUUM	On – off	On – Off	On
Pr134	M08 – A – 02	Vacuum on time	VACUUM ACTIVE	Seconds	1 – 180	25
Pr135	M08 – A – 03	Enables a Vacuum operating test to be performed	VACUUM TEST	On – off	On – off	Off

Parameters "FACTORY CALIBRATIONS" - Mod. ECO290 (i09_201118)						
Parameter	Menu level	Description	Display	Measurement	Value field	Database o0
Pr01	M08 – 6 – 01	Ignition cycle maximum time	IGNIT- MINUTES	Minutes	5 – 25	18
Pr02	M08 – 6 – 02	Start time	START MINUTES	Minutes	2 – 12	8
Pr03	M08 – 6 – 03	Time interval between the two brazier cleaning operations	BRAZIER CLEANING	Minutes	3 – 240	90
Pr04	M08 – 6 – 04	Screw feed gear motor ON time in ignition phase	IGNIT- SCREW FEED	Seconds	0.1 – 8.0	1,2
Pr05	M08 – 6 – 05	Screw feed gear motor ON time in start phase	SCREW FEED START	Seconds	0.1 – 8.0	0,8
Pr06	M08 – 6 – 06	Screw feed gear motor ON time in power 1 work phase	OUTPUT 1 SCREW FEED	Seconds	0.1 – 8.0	2,4
Pr07	M08 – 6 – 07	Screw feed gear motor ON time in power 2 work phase	OUTPUT 2 SCREW FEED	Seconds	0.1 – 8.0	3,6
Pr08	M08 – 6 – 08	Screw feed gear motor ON time in power 3 work phase	OUTPUT 3 SCREW FEED	Seconds	0.1 – 8.0	4,6
Pr09	M08 – 6 – 09	Screw feed gear motor ON time in power 4 work phase	OUTPUT 4 SCREW FEED	Seconds	0.1 – 8.0	5,4

Pr10	M08 – 6 – 10	Screw feed gear motor ON time in power 5 work phase	OUTPUT 5 SCREW FEED	Seconds	0.1 – 8.0	6,4
Pr11	M08 – 6 – 11	Alarm delay	ALARM DELAY	Seconds	0 – 120	90
Pr12	M08 – 6 – 12	Brazier cleaning duration	BRAZIER CLEANING	Seconds	0 – 120	40
Pr13	M08 – 6 – 13	Flue gas minimum temperature for considering the stove on	MINIMUM THRESHOLD	°C	40 – 600	180
Pr14	M08 – 6 – 14	Flue gas maximum temperature	MAXIMUM THRESHOLD	°C	200 – 880	880
Pr15	M08 – 6 – 15	Flue gas temperature threshold for the air exchanger start-up (NOT USED)	FAN THRESHOLD	°C	200 – 720	720
Pr16	M08 – 6 – 16	Flue gas extraction speed in ignition phase	IGNIT FLUE GAS SPEED	RPM	500 – 2800	1900
Pr17	M08 – 6 – 17	Flue gas extraction speed in start phase	START FLUE GAS SPEED	RPM	500 – 2800	1600
Pr18	M08 – 6 – 18	Flue gas extraction speed in power 1 work phase	P 1 FLUE GAS SPEED	RPM	500 – 2800	1500
Pr19	M08 – 6 – 19	Flue gas extraction speed in power 2 work phase	P 2 FLUE GAS SPEED	RPM	500 – 2800	1600
Pr20	M08 – 6 – 20	Flue gas extraction speed in power 3 work phase	P 3 FLUE GAS SPEED	RPM	500 – 2800	1800
Pr21	M08 – 6 – 21	Flue gas extraction speed in power 4 work phase	P 4 FLUE GAS SPEED	RPM	500 – 2800	2000
Pr22	M08 – 6 – 22	Flue gas extraction speed in power 5 work phase	P 5 FLUE GAS SPEED	RPM	500 – 2800	2200
Pr23	M08 – 6 – 23	Exchanger 1 motor speed in output 1 working mode (NOT USED)	AIR 1 SPEED	Volt	65 – 225	65
Pr24	M08 – 6 – 24	Exchanger 1 motor speed in output 2 working mode (NOT USED)	AIR 2 SPEED	Volt	65 – 225	65
Pr25	M08 – 6 – 25	Exchanger 1 motor speed in output 3 working mode (NOT USED)	AIR 3 SPEED	Volt	65 – 225	65
Pr26	M08 – 6 – 26	Exchanger 1 motor speed in output 4 working mode (NOT USED)	AIR 4 SPEED	Volt	65 – 225	65
Pr27	M08 – 6 – 27	Exchanger 1 motor speed in output 5 working mode (NOT USED)	AIR 5 SPEED	Volt	65 – 225	65
Pr28	M08 – 6 – 28	Threshold beneath which the appliance is considered to be OFF	THRESHOLD OFF	°C	80 – 600	140
Pr29	M08 – 6 – 29	Flue gas extraction speed in brazier cleaning phase	FLUE GAS-EXT CLEANING	RPM	500 – 2800	2600
Pr30	M08 – 6 – 30	Screw feed gear motor ON time in cleaning phase	CLEANING SCREW FEED	Seconds	0.0 – 8.0	1,8
Pr31	M08 – 6 – 31	Flue gas extractor encoder enable (NOT USED)	ENCODER	On – off	On – Off	On
Pr32	M08 – 6 – 32	Screw feed brake time	BRAKE TIME	Seconds	0.0 – 0.5	0,2
Pr33	M08 – 6 – 33	Pump activation threshold	PUMP THRESHOLD	°C	20 – 70	55
Pr34	M08 – 6 – 34	Water pressure switch enable (NOT USED)	WATER PRESSURESW.	On – off	On – Off	On
Pr35	M08 – 6 – 35	Water pressure threshold (NOT USED)	PRESSURE THRESHOLD	Bar	1.5 – 3.0	2,5
Pr36	M08 – 6 – 36	Screw feed motor reducer ON time in DHW output working mode	DHW SCREW FEED	Seconds	0.1 – 8.0	6,4
Pr37	M08 – 6 – 37	Flue gas intake speed in DHW output working mode	DHW FLUE GAS-INTAKE DEVICE	RPM	500 – 2800	2200

WIRING DIAGRAM



STANDARD WARRANTY CONDITIONS

1. General information

This standard warranty (“**Klover Warranty**”) is issued by Klover Srl, San Bonifacio, Via A. Volta no. 8, for the products shown on the website www.klover.it (the “**Products**”). The Klover Warranty does not affect the rights provided for by European directive 99/44/EC or by Italian legislative decree no. 206/2005 “Consumer Code”, where applicable.

The Klover Warranty is limited to Italy. Klover Srl invites Consumers not based in Italy to contact the dealer from which they bought the Product, to obtain the current warranty conditions.

2. Activation of Warranty

The Klover Warranty must be activated, within 60 days from the date of purchase, on the website www.klover.it in the section “*Register your warranty*”. The requested details should be completed, and a delivery note or other fiscal proof of purchase (e.g. receipt) should be attached).

Alternatively, the warranty certificate, which can be found in each Product pack (the “**Warranty Certificate**”) must be sent to Klover Srl, within the same period of 60 days from the date of purchase, by following the instructions on the certificate.

When registering or sending the guarantee, please ensure that the customer copy of the Warranty Certificate is retained. It must be duly completed and signed by the Consumer and by the installer, together with the delivery note or other form of proof of purchase, in order for the Klover Warranty to be valid.

3. Two-year Klover Warranty

The Klover Warranty covers the free repair of the Product all parts of the Product that are found to be defective at origin, due to defects confirmed by Klover Srl to be exclusively attributable to the manufacturer. If it is not possible to repair the Product in any way, it will be replaced. In both cases, there will be no change to the expiry or terms of the warranty provided when the Product was purchased.

The Klover Warranty offers all the advantages of a service guaranteed directly by Klover Srl through its network of authorised service centres (Centri di Assistenza Tecnica or “**C.A.T.**”) in Italy. The list can be found on the website www.klover.it.

The Klover Warranty will remain in effect for a period of 2 years from the date of purchase, if proven by a delivery note or other proof of purchase (e.g. receipt), stating the name of the seller, the product that was bought, and the date of purchase.

Product components replaced by an authorised dealer at the Consumer’s expense as they were “out of warranty” after expiry of the two-year period will be guaranteed by Klover Srl for one year from the date of replacement, excluding costs of intervention, labour and ancillary costs.

4. Five-year Klover Warranty

If the First Switch-on service is provided by an authorised dealer, within 3 months from the date of purchase, the Consumer will be entitled to the Warranty on the main boiler unit for a period of 5 years from the date of purchase.

The cost of the First Switch-on service is paid by the Consumer.

This Klover Warranty is valid on condition that the seasonal maintenance is performed by the local service centre as indicated in the user manual (for example, Safe Top boiler units require annual use of the Long Life protection).

The First Switch-on Report, duly completed and signed, must be kept carefully to ensure that the Klover Warranty remains operational.

5. Complaints and Assistance

As provided for by Legislative Decree 24/2002, complaints should be sent to the retailer through whom the Product was bought.

Once the retailer has checked that the Klover Warranty is in force and has not been invalidated, they will contact the local service centre to agree the terms of intervention to verify and eliminate the reported fault. If the Consumer contacts the service centre directly, the service centre must immediately inform the retailer from whom the Product was bought.

If, while inspecting the Product, the service centre finds that the reported defect is not one of the defects covered by the Warranty, the call-out and any works completed, will be paid by the Consumer.

In order to improve the service and reduce intervention time, Consumers are asked to provide the details of the Product they are calling about. In particular, the following information should be provided: • Warranty Certificate number • the name, model and serial number of the Product • the date of purchase • the reported defect.

Klover Srl will not be liable for any delays in carrying out repairs or replacements of the Product.

6. Disclaimer

Klover Products must undergo functional testing before any related masonry works are carried out (for example before tiling, installation of pilasters, or painting of the walls). Klover Srl is not liable for any costs incurred as a result of removal and/or reconstruction of related installations, or for any other ancillary intervention even if it is the result of works to replace defective parts.

Klover Srl is not liable for any faults in the Product that may be attributable to external conditions and/or events, including but not limited to insufficient installation capacity, mis-installation, lack of maintenance for maintenance not carried out in accordance with the instructions in the user manual, or misuse of the Product. The cost of any works will be paid by the Consumer in such cases.

Klover Srl declines all liability in respect of any loss or damage that may be caused directly or indirectly to the Consumer and/or to a third party or to persons, animals or property as a result of failure to comply with all the relevant instructions concerning installation, use and maintenance of the Product. The injured party must prove the loss or damage, the defect, and the causal connection, and must the retailer from which the Product was bought, in accordance with Legislative Decree 24/2002.

7. Exclusions from Klover Warranty

The Klover Warranty does not include:

- Defects in the Product that are not attributable to manufacturing defects
- Defects in the products related to mis-installation or inappropriate installation
- Defects related to improper functioning of the chimney flue
- Defects in the Product caused by negligence, accidental breakage, normal wear and tear, tampering and/or damage during transport (scratches, dents etc.), including shipments sent free to destination, works carried out by unauthorised personnel, and additional damage caused by inappropriate intervention by the Consumer
- Calibration of settings
- Damage caused by the use of expired or inappropriate fuel
- Transport costs.

The Klover Warranty excludes the following Product components:

- Ceramic or tempered glass, ceramic/majolica tiling and/or lacquered steel and/or cast iron. Changes in colour shades, speckling, superficial cracking, shading and minor dimensional variations are not considered Product defects, but are characteristics of the artisanal manufacturing process
- Painted, chromed or gilded details, handles, dials
- All the external components of the Product on which the Consumer may intervene directly during use and/or maintenance, or which may be subject to wear and tear and/or the formation of rust, or blemishes on the steel caused by harsh detergents, in particular the use of wood at a rate that exceeds the recommended hourly capacity, or the use of fuels that were not recommended or were not included in the instructions
- Refractory materials or vermiculite
- The pellet brazier, grille and cast iron cooking plate, the smoke deflector or flame guard, the seals, fuses or batteries in the Product's electronic components and any other removable component that may be subject to normal wear and tear
- Electrical and electronic parts found to be faulty as a result of non-standard electrical connections, natural disasters or voltage variations other than the nominal variation.

8. Forum

The Court of Verona will have sole jurisdiction in the event of a dispute.



F U O C O E P A S S I O N E

KLOVER Srl

Via A. Volta, 8
37047 San Bonifacio (VR)
VAT No. 02324280235
www.klover.it